

## Supported RMC CD-DVD Writers :

The Recovery Media Creator (RMC) offers a unique and universal CD and DVD writer support. This gives RMC the ability to create recovery media for the end-user using almost any CD or DVD writer available today.

Since the CD and DVD writing standard does not change rapidly, you may find that RMC is able to create media on newly developed CD and DVD writers.

If you find that RMC is not compatible with a CD or DVD writer, do not hesitate to contact the PC Angel LE Support team at [support@pcangelle.com](mailto:support@pcangelle.com) so that we can provide a future solution.

Here is a non-extensive list of supported CD and DVD writers:

### ATAPI/USB/Firewire Recorders:

"CRW-3212A"	ASUS_CRW3212	ASUS
"CRW-3212U"	ASUS_CRW3212	ASUS
"CRW-4012A"	ASUS_CRW4012	ASUS
"CRW-4816A"	ASUS_CRW4816	ASUS
"CRW-4824A"	ASUS_CRW4816	ASUS
"CRW-4824AH"	ASUS_CRW4816	ASUS
"CRW-4832A"	ASUS_CRW4816	ASUS
"CRW-5224A"	ASUS_CRW5224	ASUS
"CRW-5232A"	ASUS_CRW5224	ASUS
"CDRW/DVD SBW-161"	GENERIC_16X10X24	QSI
"DVD/CDRW SBW-161"	GENERIC_16X10X24	QSI
"IDE1612CO"	GENERIC_16X10X24	QSI
"BCE2408IM"	GENERIC_24X12X40	BTC
"BCO2408SM"	GENERIC_24X12X40	BTC
"IDE2408CO"	GENERIC_24X12X40	BTC
"CDRW-2410E"	GENERIC_24X12X40	Traxdata
"BCE3212IM"	GENERIC_32X12X40	BTC
"IDE3216CO"	GENERIC_32X12X40	BTC
"IDE3216IM"	GENERIC_32X12X40	BTC
"BCP 8000+"	GENERIC_40X12X48	BTC
"BCP 8000"	GENERIC_40X12X48	BTC
"RIP 8000"	GENERIC_40X12X48	BTC
"AXT 8000"	GENERIC_40X12X48	BTC
"GEN 8000"	GENERIC_40X12X48	BTC
"BCE4010IM"	GENERIC_40X12X48	BTC
"BCE4012IM"	GENERIC_40X12X48	BTC
"BCO4012IM"	GENERIC_40X12X48	BTC
"BCE4016IM"	GENERIC_40X12X48	BTC
"BCO4016IM"	GENERIC_40X12X48	BTC
"IDE4012"	GENERIC_40X12X48	BTC
"IDE4016"	GENERIC_40X12X48	BTC
"IDE4016CO"	GENERIC_40X12X48	BTC
"CDRW23042EXT3-B"	GENERIC_40X12X48	lomega

"CDRW23042EXT3-C" GENERIC\_40X12X48 Iomega  
"BurnMAX40" GENERIC\_40X12X48 Polaroid  
"BurnMAX40 CB" GENERIC\_40X12X48 Polaroid  
"BurnMAX40EX" GENERIC\_40X12X48 Polaroid  
"BurnMAX40EX CB" GENERIC\_40X12X48 Polaroid  
"BurnMAX40PX" GENERIC\_40X12X48 Polaroid  
"CDRW-4012E" GENERIC\_40X12X48 Traxdata  
"CW078D CD-R/RW" GENERIC\_40X12X48 CyberDrive  
"CW079D CD-R/RW" GENERIC\_40X12X48 CyberDrive  
"BCE4812IM" GENERIC\_48X16X48 BTC  
"BCE4816IM" GENERIC\_48X16X48 BTC  
"BCO4816IM" GENERIC\_48X16X48 BTC  
"IDE4812" GENERIC\_48X16X48 BTC  
"IDE4816" GENERIC\_48X16X48 BTC  
"IDE4816CO" GENERIC\_48X16X48 BTC  
"BurnMAX48" GENERIC\_48X16X48 Polaroid  
"BurnMAX48 CB" GENERIC\_48X16X48 Polaroid  
"CDRW-4812E" GENERIC\_48X16X48 Traxdata  
"CDRW-4816E" GENERIC\_48X16X48 Traxdata  
"CW088D CD-R/RW" GENERIC\_48X16X48 CyberDrive  
"CW089D CD-R/RW" GENERIC\_48X16X48 CyberDrive  
"BCE4824IM" GENERIC\_48X24X48 BTC  
"BCE4832IM" GENERIC\_48X24X48 BTC  
"IDE4824" GENERIC\_48X24X48 BTC  
"IDE4832" GENERIC\_48X24X48 BTC  
"BurnMAX48EX" GENERIC\_48X24X48 Polaroid  
"BurnMAX48EX CB" GENERIC\_48X24X48 Polaroid  
"CDRW55296INT-C" GENERIC\_48X24X48 Iomega  
"CDRW55292EXT3-C" GENERIC\_48X24X48 Iomega  
"CDRW-4824E" GENERIC\_48X24X48 Traxdata  
"481648AX" GENERIC\_48X24X48 Verbatim/Cendyne  
"BCE5216IM" GENERIC\_52X24X52 BTC  
"BCE5224IM" GENERIC\_52X24X52 BTC  
"BCE5224SO" GENERIC\_52X24X52 BTC  
"BCE5224UI" GENERIC\_52X24X52 BTC  
"BCE5232IM" GENERIC\_52X24X52 BTC  
"BCE5232SO" GENERIC\_52X24X52 BTC  
"IDE5216CO" GENERIC\_52X24X52 BTC  
"IDE5224" GENERIC\_52X24X52 BTC  
"IDE5224SO" GENERIC\_52X24X52 BTC  
"IDE5232" GENERIC\_52X24X52 BTC  
"IDE5232SO" GENERIC\_52X24X52 BTC  
"CD-RW 52X24-B0" GENERIC\_52X24X52 BTC  
"CD-RW 52X32-B0" GENERIC\_52X24X52 BTC  
"CDRW64896INT-C" GENERIC\_52X24X52 Iomega  
"CDRW64892EXT3-C" GENERIC\_52X24X52 Iomega  
"BurnMAX52" GENERIC\_52X24X52 Polaroid  
"BurnMAX52CB" GENERIC\_52X24X52 Polaroid  
"BurnMAX52EX" GENERIC\_52X24X52 Polaroid  
"BurnMAX52EX SO" GENERIC\_52X24X52 Polaroid  
"BurnMAX52SO" GENERIC\_52X24X52 Polaroid  
"CDRW-5224E" GENERIC\_52X24X52 Traxdata  
"CD-RW CRX220E2" GENERIC\_52X24X52 Sony  
"CDRW-5212E" GENERIC\_52X24X52 Traxdata  
"CDRW-5216E" GENERIC\_52X24X52 Traxdata  
"CDRW-5224E SO" GENERIC\_52X24X52 Traxdata  
"52MAXX 2452AK" GENERIC\_52X24X52 Memorex

"CR-487ETE"      GENERIC\_52X24X52    Mitsumi  
 "CR-488ETE"      GENERIC\_52X24X52    Mitsumi  
 "CD-RW RW5220E"    GENERIC\_52X24X52    Creative Labs  
 "CW098D CD-R/RW"    GENERIC\_52X24X52    CyberDrive  
 "CW099D CD-R/RW"    GENERIC\_52X24X52    CyberDrive  
 "XR-W2080"          JVC\_XRW2080          JVC  
 "XR-W2082"          JVC\_XRW2080          JVC  
 "XR-RW2224"          JVC\_XRW2080          JVC  
 "RW2224"            JVC\_XRW2080          RWD  
 "CD-RW2224"          JVC\_XRW2080          Memorex  
 "H2242"            JVC\_XRW2080          Hi-Val  
 "CD-RW RW2024E"    JVC\_XRW2080          Creative Labs  
 "CD-RW 2024E"      JVC\_XRW2080          Creative Labs  
 "XR-W4080"          JVC\_XRW4080          JVC  
 "XR-W4082"          JVC\_XRW4080          JVC  
 "XR-RW4224"          JVC\_XRW4080          JVC  
 "XR-RW4424"          JVC\_XRW4080          JVC  
 "RW4224"            JVC\_XRW4080          RWD  
 "RW4424"            JVC\_XRW4080          RWD  
 "CD-RW4224A"        JVC\_XRW4080          Smart & Friendly  
 "CD-RW4424A"        JVC\_XRW4080          Smart & Friendly  
 "H4242"            JVC\_XRW4080          Hi-Val  
 "CD-RW RW4224E"    JVC\_XRW4080          Creative Labs  
 "CD-RW RW4424E"    JVC\_XRW4080          Creative Labs  
 "CD-RW4224"        JVC\_XRW4080          Memorex  
 "CD-RW4424"        JVC\_XRW4080          Memorex  
 "CD-RW CED-8041B"    LGE\_CDRW4X24        LG Electronics  
 "CD-RW CED-8042B"    LGE\_CDRW4X24        LG Electronics  
 "CD-REWRITER-4C"    LGE\_CDRW4X24        Micro Solutions  
 "CD-RW CED-8080B"    LGE\_CDRW8X32        LG Electronics  
 "CD-RW CED-8081B"    LGE\_CDRW8X32        LG Electronics  
 "CD-RW CED-8082B"    LGE\_CDRW8X32        LG Electronics  
 "CD-RW CED-8083B"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8080B"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8081B"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8082B"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8083B"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8080N"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8081N"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8082N"    LGE\_CDRW8X32        LG Electronics  
 "Combo GCC-8083N"    LGE\_CDRW8X32        LG Electronics  
 "CD-RW GCE-8080N"    LGE\_CDRW8X32        LG Electronics  
 "CD-Writer+ 9100b"    LGE\_CDRW8X32        Hewlett Packard  
 "CD-REWRITER-8C"    LGE\_CDRW8X32        Micro Solutions  
 "CD-RW CED-8120B"    LGE\_CDRW12X40        LG Electronics  
 "CD-RW GCE-8121B"    LGE\_CDRW12X40        LG Electronics  
 "RW/DVD GCC-4120B"    LGE\_CDRW12X40        LG Electronics  
 "RW/DVD GCC-4120N"    LGE\_CDRW12X40        LG Electronics  
 "CD-Writer+ 9500b"    LGE\_CDRW12X40        Hewlett Packard  
 "CD-RW GCE-8160B"    LGE\_CDRW16X40        LG Electronics  
 "RW/DVD GCC-4160B"    LGE\_CDRW16X40        LG Electronics  
 "RW/DVD GCC-4160N"    LGE\_CDRW16X40        LG Electronics  
 "CD-Writer cd16b"    LGE\_CDRW16X40        Hewlett Packard  
 "CD-RW CW1601"        LGE\_CDRW16X40        OptoRite  
 "CD-RW 16/8/40X"     LGE\_CDRW16X40        Generic  
 "CD-RW 16/12/40X"    LGE\_CDRW16X40        Generic  
 "CD-RW GCE-8240B"    LGE\_CDRW24X40        LG Electronics

"RW/DVD GCC-4240B" LGE\_CDRW24X40 LG Electronics  
 "RW/DVD GCC-4240N" LGE\_CDRW24X40 LG Electronics  
 "CD-RW GCE-8320B" LGE\_CDRW32X40 LG Electronics  
 "RW/DVD GCC-4320B" LGE\_CDRW32X40 LG Electronics  
 "RW/DVD GCC-4320N" LGE\_CDRW32X40 LG Electronics  
 "CD-RW GCE-8400B" LGE\_CDRW40X40 LG Electronics  
 "RW/DVD GCC-4400B" LGE\_CDRW40X40 LG Electronics  
 "RW/DVD GCC-4400N" LGE\_CDRW40X40 LG Electronics  
 "CD-RW MS-8340" LGE\_CDRW40X40 MSI  
 "CD-RW CW4002" LGE\_CDRW40X40 OptoRite  
 "CD-RW GCE-8480B" LGE\_CDRW48X48 LG Electronics  
 "CD-RW GCE-8481B" LGE\_CDRW48X48 LG Electronics  
 "RW/DVD GCC-4480B" LGE\_CDRW48X48 LG Electronics  
 "RW/DVD GCC-4480N" LGE\_CDRW48X48 LG Electronics  
 "CD-RW MS-8348" LGE\_CDRW48X48 MSI  
 "CD-RW CW4802" LGE\_CDRW48X48 OptoRite  
 "CD-RW GCE-8520B" LGE\_CDRW52X52 LG Electronics  
 "CD-RW GCC-5240P" LGE\_CDRW52X52 LG Electronics  
 "CD-RW GCC-5241P" LGE\_CDRW52X52 LG Electronics  
 "CD-RW MS-8352" LGE\_CDRW48X48 MSI  
 "CD-R CW-7582" MATSHITA\_CW7582 Matsushita  
 "CDR4800" MATSHITA\_CW7582 Traxdata  
 "CDR4800E" MATSHITA\_CW7582 Creative Labs  
 "CD-RW CW-7585" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-7586" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-7586SI" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-7121" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-8571" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-8571" MATSHITA\_CW7585 Matsushita  
 "CD-RW CW-8572" MATSHITA\_CW7585 Matsushita  
 "CD-RW RW8433E" MATSHITA\_CW7585 Creative Labs  
 "CD-RW RW8433E" MATSHITA\_CW7585 Creative Labs  
 "CD-RW RW8439E" MATSHITA\_CW7585 Creative Labs  
 "CD-RW RW8439E" MATSHITA\_CW7585 Creative Labs  
 "CR-4801TE" MITSUMI\_CR4801TE Mitsumi  
 "CR-4802TE" MITSUMI\_CR4802TE Mitsumi  
 "CD-REWRITER-4B" MITSUMI\_CR4802TE Micro Solutions  
 "CR-4804TE" MITSUMI\_CR4804TE Mitsumi  
 "CR-4804TE USB" MITSUMI\_CR4804TE Mitsumi  
 "CD-Writer+ 8290" MITSUMI\_CR4804TE Hewlett Packard  
 "CD-Writer cd4f" MITSUMI\_CR4804TE Hewlett Packard  
 "CR-4805TE" MITSUMI\_CR4805TE Mitsumi  
 "CR-48X5TE" MITSUMI\_CR4805TE Mitsumi  
 "CD-Writer+ 8200f" MITSUMI\_CR4805TE Hewlett Packard  
 "CD-Writer+ 9100f" MITSUMI\_CR4805TE Hewlett Packard  
 "CD-REWRITER-8A" MITSUMI\_CR4805TE Micro Solutions  
 "BCE840IE" MITSUMI\_CR4805TE BTC  
 "CELERUS" MITSUMI\_CR4805TE Philips  
 "CR-4808TE" MITSUMI\_CR4808TE Mitsumi  
 "CR-48X8TE" MITSUMI\_CR4808TE Mitsumi  
 "CD-Writer cd16f" MITSUMI\_CR4808TE Hewlett Packard  
 "SFIX16" MITSUMI\_CR4808TE Waitec  
 "CR-4809TE" MITSUMI\_CR4809TE Mitsumi  
 "CR-48X9TE" MITSUMI\_CR4809TE Mitsumi  
 "STORM24/1" MITSUMI\_CR4809TE Waitec  
 "FREECOM24D" MITSUMI\_CR4809TE Freecom  
 "241040AB" MITSUMI\_CR4809TE Verbatim/Cendyne

"CW048D CD-R/RW" MITSUMI\_CR4809TE CyberDrive  
"CR-48XATE" MITSUMI\_CR48XATE Mitsumi  
"321240 CDRW" MITSUMI\_CR48XATE Philips  
"R/RW 32x10" MITSUMI\_CR48XATE Philips  
"R/RW 32x12" MITSUMI\_CR48XATE Philips  
"STORM32/1" MITSUMI\_CR48XATE Waitec  
"STORM32/2" MITSUMI\_CR48XATE Waitec  
"SFINX32" MITSUMI\_CR48XATE Waitec  
"FREECOM32D" MITSUMI\_CR48XATE Freecom  
"321240AB" MITSUMI\_CR48XATE Verbatim/Cendyne  
"CW058D CD-R/RW" MITSUMI\_CR48XATE CyberDrive  
"EW058U CD-R/RW" MITSUMI\_CR48XATE CyberDrive  
"CD-R/RW 32X10" MITSUMI\_CR48XATE Acer  
"CD-R/RW 32X12" MITSUMI\_CR48XATE Acer  
"CD-R/RW 32X12X40" MITSUMI\_CR48XATE Acer  
"CR-48XCTE" MITSUMI\_CR48XCTE Mitsumi  
"401240 CDRW" MITSUMI\_CR48XCTE Philips  
"401248 CDRW" MITSUMI\_CR48XCTE Philips  
"STORM40/1" MITSUMI\_CR48XCTE Waitec  
"FREECOM40D" MITSUMI\_CR48XCTE Freecom  
"401248AB" MITSUMI\_CR48XCTE Verbatim/Cendyne  
"CW068D CD-R/RW" MITSUMI\_CR48XCTE CyberDrive  
"EW068U CD-R/RW" MITSUMI\_CR48XCTE CyberDrive  
"CD-R/RW 40X12" MITSUMI\_CR48XCTE Acer  
"CR-48XFTE" MITSUMI\_CR48XFTE Mitsumi  
"482448 CDRW" MITSUMI\_CR48XFTE Philips  
"STORM48/1" MITSUMI\_CR48XFTE Waitec  
"481248AB" MITSUMI\_CR48XFTE Verbatim/Cendyne  
"481648AB" MITSUMI\_CR48XFTE Verbatim/Cendyne  
"CD-R/RW 48X12" MITSUMI\_CR48XFTE Acer  
"CD-R/RW 48X16" MITSUMI\_CR48XFTE Acer  
"CD-R/RW 48X20" MITSUMI\_CR48XFTE Acer  
"CDD3610" PHILIPS\_CDD3600 Philips  
"CDD3610 CD-R/RW" PHILIPS\_CDD3600 Philips  
"PCA267CR" PHILIPS\_CDD3600 Philips  
"DEVELOPMENT - 97" PHILIPS\_CDD3600 Philips  
"ReWritable-2x2x6" PHILIPS\_CDD3600 Philips  
"CD-Writer+ 7100" PHILIPS\_CDD3600 Hewlett Packard  
"CD-Writer+ 7200" PHILIPS\_CDD3600 Hewlett Packard  
"CR-622" PHILIPS\_CDD3600 Memorex  
"CRW-1622" PHILIPS\_CDD3600 Memorex  
"CDRW-622" PHILIPS\_CDD3600 Wearnes  
"CDRW-2422" PHILIPS\_CDD3600 Wearnes  
"CD-R/RW CRW6206A" PHILIPS\_CDD3600 Acer  
"CD-R/RW 2X2X6" PHILIPS\_CDD3600 Acer  
"BCE 621E" PHILIPS\_CDD3600 BTC  
"SOCRATES" PHILIPS\_CDD3600 OTI  
"WT2036EI" PHILIPS\_CDD3600 Waitec  
"CDRW602" PHILIPS\_CDD3600 CyberDrive  
"CDRW602 1.20" PHILIPS\_CDD3600 CyberDrive  
"ODE6121" PHILIPS\_CDD3600 Delta  
"ODE-6121" PHILIPS\_CDD3600 Delta  
"ODR6121" PHILIPS\_CDD3600 Delta  
"ODR-6121" PHILIPS\_CDD3600 Delta  
"CDR6121" PHILIPS\_CDD3600 Delta  
"CDE6121" PHILIPS\_CDD3600 Delta  
"CD-R/RW SCW-230" PHILIPS\_CDD3600 Samsung

"CD-R/RW SCW-430" PHILIPS\_CDD3600 Samsung  
"CDRW2260+" PHILIPS\_CDD3600 Traxdata  
"JCD-62RW" PHILIPS\_CDD3600 JCCOM  
"CDD3801 CD-R/RW" PHILIPS\_CDD3800 Philips  
"PCA382RW IDE" PHILIPS\_CDD3800 Philips  
"R/RW 2x2x24" PHILIPS\_CDD3800 Philips  
"CDRW-2224" PHILIPS\_CDD3800 Memorex  
"ZIPCD 650" PHILIPS\_CDD3800 Iomega  
"WT2422EI" PHILIPS\_CDD3800 Waitec  
"CDRW2224 PLUS" PHILIPS\_CDD3800 Traxdata  
"CD-R/RW CRW6232A" PHILIPS\_CDD3800 Acer  
"CD-R/RW 2X2X32" PHILIPS\_CDD3800 Acer  
"CD-R/RW 2X2X24" PHILIPS\_CDD3800 Acer  
"BCE242IE" PHILIPS\_CDD3800 BTC  
"CDD4201 CD-R/RW" PHILIPS\_CDD4200 Philips  
"R/RW 4x4x24" PHILIPS\_CDD4200 Philips  
"CD-Writer+ 8000" PHILIPS\_CDD4200 Hewlett Packard  
"CD-R/RW SW-204B" PHILIPS\_CDD4200 Samsung  
"CD-R/RW SW-204F" PHILIPS\_CDD4200 Samsung  
"COMBO SM-304B" PHILIPS\_CDD4200 Samsung  
"CDRW/DVD SM-304B" PHILIPS\_CDD4200 Samsung  
"CD-R/RW CRW4424A" PHILIPS\_CDD4200 Acer  
"CD-R/RW 4X4X24" PHILIPS\_CDD4200 Acer  
"CD-R/RW CRW4230A" PHILIPS\_CDD4200 Acer  
"CD-R/RW 4X2X30" PHILIPS\_CDD4200 Acer  
"CD-R/RW CRW4430A" PHILIPS\_CDD4200 Acer  
"CD-R/RW 4X4X30" PHILIPS\_CDD4200 Acer  
"CD-R/RW CRW4232A" PHILIPS\_CDD4200 Acer  
"CD-R/RW 4X2X32" PHILIPS\_CDD4200 Acer  
"CD-R/RW CRW4432A" PHILIPS\_CDD4200 Acer  
"CD-R/RW 4X4X32" PHILIPS\_CDD4200 Acer  
"ZIPCD 650 USB" PHILIPS\_CDD4200 Iomega  
"ZIPCD 4x650" PHILIPS\_CDD4200 Iomega  
"WT2444EI" PHILIPS\_CDD4200 Waitec  
"CDRW4424 PLUS" PHILIPS\_CDD4200 Traxdata  
"CD-REWRITER-4E" PHILIPS\_CDD4200 Micro Solutions  
"CW043D CD-R/RW" PHILIPS\_CDD4200 CyberDrive  
"BCE324IE" PHILIPS\_CDD4200 BTC  
"BCE424IE" PHILIPS\_CDD4200 BTC  
"CDD4401 CD-R/RW" PHILIPS\_CDD4400 Philips  
"PCRW404" PHILIPS\_CDD4400 Philips  
"R/RW 4x4x32" PHILIPS\_CDD4400 Philips  
"CDRW4432 PLUS" PHILIPS\_CDD4400 Traxdata  
"WT3244EI" PHILIPS\_CDD4400 Waitec  
"CDRW-4424" PHILIPS\_CDD4400 Wearnes  
"CD-R/RW 6X4X30" PHILIPS\_CDD4600 Acer  
"CD-R/RW CRW6430A" PHILIPS\_CDD4600 Acer  
"CD-R/RW 6X4X32" PHILIPS\_CDD4600 Acer  
"CD-R/RW CRW6432A" PHILIPS\_CDD4600 Acer  
"CDD4801 CD-R/RW" PHILIPS\_CDD4800 Philips  
"PCRW804" PHILIPS\_CDD4800 Philips  
"R/RW 8x4x32" PHILIPS\_CDD4800 Philips  
"CD-Writer+ 9100c" PHILIPS\_CDD4800 Hewlett Packard  
"CD-Writer+ 9200c" PHILIPS\_CDD4800 Hewlett Packard  
"CD-R/RW SW-208B" PHILIPS\_CDD4800 Samsung  
"CD-R/RW SW-208F" PHILIPS\_CDD4800 Samsung  
"COMBO SM-308B" PHILIPS\_CDD4800 Samsung

"CDRW/DVD SM-308B" PHILIPS\_CDD4800 Samsung  
"CD-R/RW 8X4X24" PHILIPS\_CDD4800 Acer  
"CD-R/RW CRW8424A" PHILIPS\_CDD4800 Acer  
"CD-R/RW 8X4X30" PHILIPS\_CDD4800 Acer  
"CD-R/RW CRW8430A" PHILIPS\_CDD4800 Acer  
"CD-R/RW 8X4X32" PHILIPS\_CDD4800 Acer  
"CD-R/RW CRW8432A" PHILIPS\_CDD4800 Acer  
"ZIPCD 8x650" PHILIPS\_CDD4800 Iomega  
"ZIPCD1024INT-A" PHILIPS\_CDD4800 Iomega  
"ZIPCD1024EXT" PHILIPS\_CDD4800 Iomega  
"SHUTTLE 8432" PHILIPS\_CDD4800 Waitec  
"CDRW-8432i" PHILIPS\_CDD4800 Wearnes  
"CD-RW RW8435E" PHILIPS\_CDD4800 Creative Labs  
"CD-RW RW8438E" PHILIPS\_CDD4800 Creative Labs  
"CW018D CD-R/RW" PHILIPS\_CDD4800 CyberDrive  
"CW017D CD-R/RW" PHILIPS\_CDD4800 CyberDrive  
"BCE832IE" PHILIPS\_CDD4800 BTC  
"CD-R/RW 10X4X32" PHILIPS\_CDRW1004 Acer  
"CD-R/RW 10X8X32" PHILIPS\_CDRW1004 Acer  
"PCRW1208" PHILIPS\_CDRW1208 Philips  
"PCRW1208A" PHILIPS\_CDRW1208 Philips  
"PCRW1208MR" PHILIPS\_CDRW1208 Philips  
"PCRW1208JR" PHILIPS\_CDRW1208 Philips  
"PCRW1208UE" PHILIPS\_CDRW1208 Philips  
"CDD4851 CD-R/RW" PHILIPS\_CDRW1208 Philips  
"R/RW 12x8" PHILIPS\_CDRW1208 Philips  
"R/RW 12x10" PHILIPS\_CDRW1208 Philips  
"CD-R/RW SW-212B" PHILIPS\_CDRW1208 Samsung  
"CD-R/RW SW-212F" PHILIPS\_CDRW1208 Samsung  
"CD-R/RW 12X8X32" PHILIPS\_CDRW1208 Acer  
"SAURUS" PHILIPS\_CDRW1208 Waitec  
"DATA 32X12X8" PHILIPS\_CDRW1208 Diamond  
"CW028D CD-R/RW" PHILIPS\_CDRW1208 CyberDrive  
"PCRW1610" PHILIPS\_CDRW1610 Philips  
"PCRW1610A" PHILIPS\_CDRW1610 Philips  
"CDRW1610" PHILIPS\_CDRW1610 Philips  
"CDRW1610A" PHILIPS\_CDRW1610 Philips  
"CDRW1612" PHILIPS\_CDRW1610 Philips  
"CDRW1612A" PHILIPS\_CDRW1610 Philips  
"CDRWDVD1610" PHILIPS\_CDRW1610 Philips  
"CDRWDVD1612" PHILIPS\_CDRW1610 Philips  
"R/RW 16x10A" PHILIPS\_CDRW1610 Philips  
"R/RW 16x12A" PHILIPS\_CDRW1610 Philips  
"RW16x8/DVD" PHILIPS\_CDRW1610 Philips  
"RW16x10/DVD" PHILIPS\_CDRW1610 Philips  
"RW16x12/DVD" PHILIPS\_CDRW1610 Philips  
"CD-Writer cd16c" PHILIPS\_CDRW1610 Hewlett Packard  
"CD-R/RW 16X10" PHILIPS\_CDRW1610 Acer  
"ALADAR" PHILIPS\_CDRW1610 Waitec  
"DATA 40X16X10" PHILIPS\_CDRW1610 Diamond  
"CW038D CD-R/RW" PHILIPS\_CDRW1610 CyberDrive  
"PCRW2010" PHILIPS\_CDRW2010 Philips  
"PCRW2010A" PHILIPS\_CDRW2010 Philips  
"CDRW2010" PHILIPS\_CDRW2010 Philips  
"CDRW2010A" PHILIPS\_CDRW2010 Philips  
"CDRWDVD2010" PHILIPS\_CDRW2010 Philips  
"R/RW 20x10" PHILIPS\_CDRW2010 Philips

"CD-R/RW 20X10" PHILIPS\_CDRW2010 Acer  
"LTR-20101B" PHILIPS\_CDRW2010 Lite-On  
"DATA 40X20X10" PHILIPS\_CDRW2010 Diamond  
"PCRW2410" PHILIPS\_CDRW2410 Philips  
"PCRW2410A" PHILIPS\_CDRW2410 Philips  
"CDRW2410" PHILIPS\_CDRW2410 Philips  
"CDRW2410A" PHILIPS\_CDRW2410 Philips  
"PCRW2412" PHILIPS\_CDRW2410 Philips  
"CDRW2412" PHILIPS\_CDRW2410 Philips  
"CDRW2412A" PHILIPS\_CDRW2410 Philips  
"CDRWDVD2410" PHILIPS\_CDRW2410 Philips  
"CDRWDVD2412" PHILIPS\_CDRW2410 Philips  
"RW24x10/DVD" PHILIPS\_CDRW2410 Philips  
"RW24x12/DVD" PHILIPS\_CDRW2410 Philips  
"R/RW 24x10A" PHILIPS\_CDRW2410 Philips  
"R/RW 24x12A" PHILIPS\_CDRW2410 Philips  
"241040 CDRW" PHILIPS\_CDRW2410 Philips  
"241240 CDRW" PHILIPS\_CDRW2410 Philips  
"CD-R/RW 24X10" PHILIPS\_CDRW2410 Acer  
"DATA 40X24X10" PHILIPS\_CDRW2410 Diamond  
"CDRW3210" PHILIPS\_CDRW3210 Philips  
"CDRW3210A" PHILIPS\_CDRW3210 Philips  
"CDRWDVD3210" PHILIPS\_CDRW3210 Philips  
"CDRWDVD3212" PHILIPS\_CDRW3210 Philips  
"CD-R/RW 32X10" PHILIPS\_CDRW3210 Acer  
"DATA 40X32X10" PHILIPS\_CDRW3210 Diamond  
"CDRW4012" PHILIPS\_CDRW4012 Philips  
"CDRW4012A" PHILIPS\_CDRW4012 Philips  
"CDRW4012P" PHILIPS\_CDRW4012 Philips  
"CDRW4016A" PHILIPS\_CDRW4012 Philips  
"CDRWDVD4010" PHILIPS\_CDRW4012 Philips  
"CDRWDVD4012" PHILIPS\_CDRW4012 Philips  
"R/RW 40x12A" PHILIPS\_CDRW4012 Philips  
"R/RW 40x16A" PHILIPS\_CDRW4012 Philips  
"CDRW4824" PHILIPS\_CDRW4824 Philips  
"CDRW4824A" PHILIPS\_CDRW4824 Philips  
"CDRWDVD4824" PHILIPS\_CDRW4824 Philips  
"CDRW48A" PHILIPS\_CDRW4824 Philips  
"R/RW 48xA" PHILIPS\_CDRW4824 Philips  
"CDRW5224" PHILIPS\_CDRW5224 Philips  
"CDRW5224A" PHILIPS\_CDRW5224 Philips  
"CDRWDVD5224" PHILIPS\_CDRW5224 Philips  
"DVD-RW DVR-103" PIONEER\_DVR103 Pioneer  
"DVD-RW DVR-303" PIONEER\_DVR103 Pioneer  
"DVD-RW GMA-4020B" PIONEER\_DVR103 LG Electronics  
"DVD-RW DVR-104" PIONEER\_DVR104 Pioneer  
"DRW-0208P" PIONEER\_DVR104 ASUS  
"DVDRW0200E" PIONEER\_DVR104 Generic  
"DVDRW0200W" PIONEER\_DVR104 Generic  
"DVD-RW DVR-105" PIONEER\_DVR105 Pioneer  
"DVD-RW DVR-K11" PIONEER\_DVR105 Pioneer  
"DVD RW DW-M10A" PIONEER\_DVR105 Sony  
"DVD-ROM SD-R5002" PIONEER\_DVR105 Toshiba  
"DVD-ROM SD-R5112" PIONEER\_DVR105 Toshiba  
"DVD-ROM SD-R6012" PIONEER\_DVR105 Toshiba  
"DVD-RW DRW-0402P" PIONEER\_DVR105 ASUS  
"DRW-0402P" PIONEER\_DVR105 ASUS

"DVDRW0400E" PIONEER\_DVR105 Generic  
"DVDRW0400W" PIONEER\_DVR105 Generic  
"CD-R PX-W8432T" PLEXTOR\_PXW8432 Plextor  
"CD-RW RW8432E" PLEXTOR\_PXW8432 Creative Labs  
"CDRW8432" PLEXTOR\_PXW8432 TDK  
"CD-R WT3284" PLEXTOR\_PXW8432 Waitec  
"CD-R PX-W124T" PLEXTOR\_PXW124 Plextor  
"CD-R PX-W1210A" PLEXTOR\_PXW1210 Plextor  
"CD-RW RW121032E" PLEXTOR\_PXW1210 Creative Labs  
"CDRW121032" PLEXTOR\_PXW1210 TDK  
"ZIPCD3840INT-A" PLEXTOR\_PXW1210 Iomega  
"CD-R PX-W1610A" PLEXTOR\_PXW1610 Plextor  
"CD-Writer+ 9700p" PLEXTOR\_PXW1610 Hewlett Packard  
"CDRW161040" PLEXTOR\_PXW1610 TDK  
"CDRW6400INT" PLEXTOR\_PXW1610 Iomega  
"CD-R PX-W2410A" PLEXTOR\_PXW2410 Plextor  
"CDRW241040" PLEXTOR\_PXW2410 TDK  
"CD-Writer cd24p" PLEXTOR\_PXW2410 Hewlett Packard  
"CDRW9600INT-A" PLEXTOR\_PXW2410 Iomega  
"CD-R PX-W4012A" PLEXTOR\_PXW4012 Plextor  
"CDRW19200INT-A" PLEXTOR\_PXW4012 Iomega  
"CD-R PX-W4824A" PLEXTOR\_PXW4824 Plextor  
"CD-R PX-W4824U" PLEXTOR\_PXW4824 Plextor  
"CD-R PX-W5224A" PLEXTOR\_PXW5232 Plextor  
"CD-R PREMIUM" PLEXTOR\_PXW5232 Plextor  
"CD-R PX-S88T" PLEXTOR\_PXS88 Plextor  
"CD-R/RW SCW-081" PLEXTOR\_PXS88 QSI  
"CD-RW SCW-081" PLEXTOR\_PXS88 QSI  
"CD-R PX-320A" PLEXTOR\_PX320 Plextor  
"CDRW/DVD SBW-241" QSI\_SBW241 QSI  
"CDRW/DVD SBW-242" QSI\_SBW241 QSI  
"DVD/CDRW SBW-242" QSI\_SBW241 QSI  
"CDRW/DVD SBW242U" QSI\_SBW241 QSI  
"CDRW/DVD DBW-481" QSI\_DBW481 QSI  
"MP6200A" RICOH\_MP6200A Ricoh  
"OMNIWRITER26A" RICOH\_MP6200A Philips  
"CRW620" RICOH\_MP6200A Acer  
"CRW622" RICOH\_MP6200A Acer  
"CD-REWRITER-2A" RICOH\_MP6200A Micro Solutions  
"CD-R/RW MP7030A" RICOH\_MP7040 Ricoh  
"CD-R/RW RW7030A" RICOH\_MP7040 Ricoh  
"CD-R/RW MP7040A" RICOH\_MP7040 Ricoh  
"CD-R/RW RW7040A" RICOH\_MP7040 Ricoh  
"CD-RW IMW040420" RICOH\_MP7040 Imation  
"ARW4420" RICOH\_MP7040 Actima  
"CRW9420" RICOH\_MP7040 A-Open  
"CDRW4420" RICOH\_MP7040 Memorex  
"CDRW-4420" RICOH\_MP7040 Memorex  
"MCD-RW44-20" RICOH\_MP7040 Maxell  
"OME-W141" RICOH\_MP7040 Delta  
"OIP-PW2004A" RICOH\_MP7040 Delta  
"OIP-RW2004A" RICOH\_MP7040 Delta  
"CD-REWRITER-4D" RICOH\_MP7040 Micro Solutions  
"CDRW4420a" RICOH\_MP7040 Mitsubishi  
"CD-RW CDW-U4424" RICOH\_MP7040 TORISAN  
"UJDA310" RICOH\_MP7040 Matsushita  
"CD-R/RW MP7060A" RICOH\_MP7060 Ricoh

"CD-R/RW RW7060A"	RICOH_MP7060	Ricoh
"CD-R/RW MP7063A"	RICOH_MP7060	Ricoh
"CD-R/RW RW7063A"	RICOH_MP7060	Ricoh
"CD-RW RW6424E"	RICOH_MP7060	Creative Labs
"CDRW-6424"	RICOH_MP7060	Memorex
"CD-RW6424A"	RICOH_MP7060	Smart & Friendly
"CD-R/RW SW-206"	RICOH_MP7060	Samsung
"CD-R/RW SW-207F"	RICOH_MP7060	Samsung
"CRW9624"	RICOH_MP7060	A-Open
"DVD/CDRW MP9060"	RICOH_MP7060	Ricoh
"DVD/CDRW RW9060"	RICOH_MP7060	Ricoh
"CDRW/DVD 6424-4"	RICOH_MP7060	Memorex
"ZIPCD-DVDROM"	RICOH_MP7060	lomega
"DRW4624"	RICOH_MP7060	A-Open
"MDVDRW6424"	RICOH_MP7060	Generic
"DVD/RW 4X6X4X24"	RICOH_MP7060	Generic
"UJDA320"	RICOH_MP7060	Matsushita
"CD-R/RW MP7080A"	RICOH_MP7080	Ricoh
"CD-R/RW RW7080A"	RICOH_MP7080	Ricoh
"CD-R/RW MP7083A"	RICOH_MP7080	Ricoh
"CD-R/RW RW7083A"	RICOH_MP7080	Ricoh
"CD-R/RW SW-408B"	RICOH_MP7080	Samsung
"CDRW/DVD SM-408B"	RICOH_MP7080	Samsung
"CDRW/DVD SN-308B"	RICOH_MP7080	Samsung
"CDRW8432"	RICOH_MP7080	Memorex
"CRW9832"	RICOH_MP7080	A-Open
"UJDA330"	RICOH_MP7080	Matsushita
"UJDA340"	RICOH_MP7080	Matsushita
"CD-R/RW MP7120A"	RICOH_MP7120	Ricoh
"CD-R/RW RW7120A"	RICOH_MP7120	Ricoh
"CRW1232"	RICOH_MP7120	A-Open
"TwelveMAXX 1032"	RICOH_MP7120	Memorex
"12X10X32 CD-RW"	RICOH_MP7120	BUSlink
"CD-R/RW MP7125A"	RICOH_MP7125	Ricoh
"CD-R/RW MP7125AP"	RICOH_MP7125	Ricoh
"CD-R/RW RW7125A"	RICOH_MP7125	Ricoh
"DVD/CDRW MP9120"	RICOH_MP7125	Ricoh
"DVD/CDRW RW9120"	RICOH_MP7125	Ricoh
"CDRW/DVD SM-312B"	RICOH_MP7125	Samsung
"CDRW/DVD SM-312F"	RICOH_MP7125	Samsung
"CD-Writer+ 9900j"	RICOH_MP7125	Hewlett Packard
"CD-RW CRW1232 A"	RICOH_MP7125	A-Open
"CD-RW CRW1232PRO"	RICOH_MP7125	A-Open
"CD-Writer cd12n"	RICOH_MP7125	Hewlett Packard
"CD-Writer cd12r"	RICOH_MP7125	Hewlett Packard
"CDRW121032A"	RICOH_MP7125	TDK
"NR-7700A"	RICOH_MP7125	NEC
"TwelveMAXX 1032A"	RICOH_MP7125	Memorex
"TwelveMAXX 1032P"	RICOH_MP7125	Memorex
"12X10X32 CD-RW P"	RICOH_MP7125	BUSlink
"12X10X32 CD-RW A"	RICOH_MP7125	BUSlink
"CD-R/RW MP7163A"	RICOH_MP7163	Ricoh
"CD-R/RW RW7163A"	RICOH_MP7163	Ricoh
"CD-R/RW SW-216B"	RICOH_MP7163	Samsung
"CDRW/DVD SM-316B"	RICOH_MP7163	Samsung
"CDRW/DVD SM-316F"	RICOH_MP7163	Samsung
"CD-RW CRW1632"	RICOH_MP7163	A-Open

"CD-Writer cd16n" RICOH\_MP7163 Hewlett Packard  
 "NR-7800A" RICOH\_MP7163 NEC  
 "NR-7800B" RICOH\_MP7163 NEC  
 "CD-RW NR-7800A" RICOH\_MP7163 NEC  
 "IMW161032IA" RICOH\_MP7163 Imation  
 "FREECOM16B" RICOH\_MP7163 Freecom  
 "UJDA730" RICOH\_MP7163 Matsushita  
 "CD-R/RW SR-C8102" RICOH\_MP7163 Toshiba  
 "16X10X32 CD-RW" RICOH\_MP7163 BUSlink  
 "CD-R/RW MP7200A" RICOH\_MP7200 Ricoh  
 "CD-R/RW RW7200A" RICOH\_MP7200 Ricoh  
 "DVD/CDRW MP9200" RICOH\_MP7200 Ricoh  
 "DVD/CDRW RW9200" RICOH\_MP7200 Ricoh  
 "CD-R/RW SW-220B" RICOH\_MP7200 Samsung  
 "CD-Writer cd20j" RICOH\_MP7200 Hewlett Packard  
 "CD-RW CRW2040" RICOH\_MP7200 A-Open  
 "RW-201040" RICOH\_MP7200 QPS  
 "20X10X40 CD-RW" RICOH\_MP7200 BUSlink  
 "CD-R/RW MP7240A" RICOH\_MP7240 Ricoh  
 "CD-R/RW RW7240A" RICOH\_MP7240 Ricoh  
 "CD-R/RW SW-224B" RICOH\_MP7240 Samsung  
 "CD-R/RW SW-224F" RICOH\_MP7240 Samsung  
 "CDRW/DVD SN-324B" RICOH\_MP7240 Samsung  
 "CDRW/DVD SN-324F" RICOH\_MP7240 Samsung  
 "CDRW/DVD SU-324B" RICOH\_MP7240 Samsung  
 "CDRW/DVD SU-324F" RICOH\_MP7240 Samsung  
 "NR-7900A" RICOH\_MP7240 NEC  
 "CD-RW CRW2440" RICOH\_MP7240 A-Open  
 "CD-RW CRW2448" RICOH\_MP7240 A-Open  
 "CQ2440" RICOH\_MP7240 A-Open  
 "CD-RW CRX175E2" RICOH\_MP7240 Sony  
 "RW-241040" RICOH\_MP7240 QPS  
 "CRW2440PRO" RICOH\_MP7240 Traxdata  
 "IMW241040IAB" RICOH\_MP7240 Imation  
 "FREECOM24B" RICOH\_MP7240 Freecom  
 "UJDD410" RICOH\_MP7240 Matsushita  
 "UJDA740" RICOH\_MP7240 Matsushita  
 "DVD-ROM SD-R2312" RICOH\_MP7240 Toshiba  
 "24X10X40 CD-RW" RICOH\_MP7240 BUSlink  
 "24X10X48 CD-RW" RICOH\_MP7240 BUSlink  
 "CD-R/RW MP7320A" RICOH\_MP7320 Ricoh  
 "CD-R/RW RW7320A" RICOH\_MP7320 Ricoh  
 "CD-RW MP7320A" RICOH\_MP7320 Ricoh  
 "CD-RW RW7320A" RICOH\_MP7320 Ricoh  
 "CD-R/RW SW-232B" RICOH\_MP7320 Samsung  
 "CD-R/RW SW-232F" RICOH\_MP7320 Samsung  
 "CDRW/DVD SM-332B" RICOH\_MP7320 Samsung  
 "CDRW/DVD SM-332F" RICOH\_MP7320 Samsung  
 "CD-RW CRW3248" RICOH\_MP7320 A-Open  
 "32X12X48 CD-RW" RICOH\_MP7320 A-Open  
 "CQ3248" RICOH\_MP7320 A-Open  
 "CD-RW RW3260E" RICOH\_MP7320 Creative Labs  
 "RW-321040" RICOH\_MP7320 QPS  
 "RW-321048" RICOH\_MP7320 QPS  
 "IMW321248IA" RICOH\_MP7320 Imation  
 "DVD-ROM SD-R1312" RICOH\_MP7320 Toshiba  
 "32X12X48 CD-RW" RICOH\_MP7320 BUSlink

"32x12x48 CDR-RW" RICOH\_MP7320 Generic  
"CD-R/RW MP7400A" RICOH\_MP7400 Ricoh  
"CD-R/RW RW7400A" RICOH\_MP7400 Ricoh  
"CD-RW MP7400A" RICOH\_MP7400 Ricoh  
"CD-RW RW7400A" RICOH\_MP7400 Ricoh  
"MP7400A" RICOH\_MP7400 Ricoh  
"RW7400A" RICOH\_MP7400 Ricoh  
"CD-R/RW SW-240B" RICOH\_MP7400 Samsung  
"CD-R/RW SW-240F" RICOH\_MP7400 Samsung  
"CDRW/DVD SM-340B" RICOH\_MP7400 Samsung  
"CDRW/DVD SM-340F" RICOH\_MP7400 Samsung  
"CD-RW CRW4048" RICOH\_MP7400 A-Open  
"CD-RW CRW4050" RICOH\_MP7400 A-Open  
"40X12X50 CD-RW" RICOH\_MP7400 A-Open  
"CQ4048" RICOH\_MP7400 A-Open  
"CD-RW CRX195E4" RICOH\_MP7400 Sony  
"CD-RW RW4012E" RICOH\_MP7400 Creative Labs  
"RW-401248" RICOH\_MP7400 QPS  
"CD-RW NR-9100A" RICOH\_MP7400 NEC  
"CD-RW NR-9200A" RICOH\_MP7400 NEC  
"IMW401248IA" RICOH\_MP7400 Imation  
"FREECOM40B" RICOH\_MP7400 Freecom  
"FREECOM40B1" RICOH\_MP7400 Freecom  
"UJDD420" RICOH\_MP7400 Matsushita  
"40X12X48 CD-RW" RICOH\_MP7400 BUSlink  
"40X12X50 CD-RW" RICOH\_MP7400 BUSlink  
"WRR-4048" RICOH\_MP7400 Artec  
"WSM-4048" RICOH\_MP7400 Artec  
"LCW-E40U2" RICOH\_MP7400 Generic  
"LCW-E40FU2" RICOH\_MP7400 Generic  
"DM-828" RICOH\_MP7400 Generic  
"CD-R/RW MP7480A" RICOH\_MP7480 Ricoh  
"CD-R/RW RW7480A" RICOH\_MP7480 Ricoh  
"CD-RW MP7480A" RICOH\_MP7480 Ricoh  
"CD-RW RW7480A" RICOH\_MP7480 Ricoh  
"CD-R/RW SW-248B" RICOH\_MP7480 Samsung  
"CD-R/RW SW-248F" RICOH\_MP7480 Samsung  
"CD-R/RW SW-248S" RICOH\_MP7480 Samsung  
"CDRW/DVD SM-348B" RICOH\_MP7480 Samsung  
"CDRW/DVD SM-348F" RICOH\_MP7480 Samsung  
"CD-RW CRW4848" RICOH\_MP7480 A-Open  
"CD-RW CRW4850" RICOH\_MP7480 A-Open  
"CD-RW CRW4852" RICOH\_MP7480 A-Open  
"CQ4848" RICOH\_MP7480 A-Open  
"RW-481248" RICOH\_MP7480 QPS  
"CD-RW NR-9300A" RICOH\_MP7480 NEC  
"48X24X52 CD-RW" RICOH\_MP7480 BUSlink  
"48X12X50 CD-RW" RICOH\_MP7480 BUSlink  
"WRR-4848" RICOH\_MP7480 Artec  
"WSM-4848" RICOH\_MP7480 Artec  
"CD-RW4812" RICOH\_MP7480 Generic  
"CD-R/RW MP7520A" RICOH\_MP7520 Ricoh  
"CD-R/RW RW7520A" RICOH\_MP7520 Ricoh  
"CD-RW MP7520A" RICOH\_MP7520 Ricoh  
"CD-RW RW7520A" RICOH\_MP7520 Ricoh  
"CD-R/RW SW-252B" RICOH\_MP7520 Samsung  
"CD-R/RW SW-252F" RICOH\_MP7520 Samsung

"CD-R/RW SW-252N"	RICOH_MP7520	Samsung
"CD-R/RW SW-252S"	RICOH_MP7520	Samsung
"CDRW/DVD SM-252B"	RICOH_MP7520	Samsung
"CD-RW CRW5224"	RICOH_MP7520	A-Open
"CD-RW CRW5232"	RICOH_MP7520	A-Open
"52X24X52 CD-RW"	RICOH_MP7520	A-Open
"52X32X52 CD-RW"	RICOH_MP7520	A-Open
"CQ5252"	RICOH_MP7520	A-Open
"CD-RW NR-9400A"	RICOH_MP7520	NEC
"STORM52/2"	RICOH_MP7520	Waitec
"STORM52/3"	RICOH_MP7520	Waitec
"52X24X52 CD-RW"	RICOH_MP7520	BUSlink
"WRR-5252"	RICOH_MP7520	Artec
"CD-R/RW MP8040A"	RICOH_MP8040	Ricoh
"CD-R/RW RW8040A"	RICOH_MP8040	Ricoh
"CD-REWRITER-4F"	RICOH_MP8040	Micro Solutions
"NR-8400A"	RICOH_MP8040	NEC
"UJDA710"	RICOH_MP8040	Matsushita
"CD-R/RW MP8080A"	RICOH_MP8080	Ricoh
"CD-R/RW RW8080A"	RICOH_MP8080	Ricoh
"CD-R/RW MP8088A"	RICOH_MP8080	Ricoh
"CD-R/RW RW8088A"	RICOH_MP8080	Ricoh
"CD-R/RW MP8088P"	RICOH_MP8080	Ricoh
"CD-R/RW RW8088P"	RICOH_MP8080	Ricoh
"NR-8500A"	RICOH_MP8080	NEC
"UJDA720"	RICOH_MP8080	Matsushita
"CD-R/RW SR-C8002"	RICOH_MP8080	Toshiba
"DVD+RW MP5120"	RICOH_MP5120	Ricoh
"DVD+RW RW5120"	RICOH_MP5120	Ricoh
"DVD Writer 100j"	RICOH_MP5120	Hewlett Packard
"DVDRW1208"	RICOH_MP5120	Philips
"DVDRW6001"	RICOH_MP5120	Philips
"DVD+RW-D01"	RICOH_MP5120	Philips
"DVD+RW ND-1000A"	RICOH_MP5120	NEC
"DVD+RW MP5125"	RICOH_MP5125	Ricoh
"DVD+RW RW5125"	RICOH_MP5125	Ricoh
"DVD+RW DRU-120A"	RICOH_MP5125	Sony
"DVD Writer 200j"	RICOH_MP5125	Hewlett Packard
"DVD Writer 300n"	RICOH_MP5125	Hewlett Packard
"DVDRW228"	RICOH_MP5125	Philips
"DVDRW248"	RICOH_MP5125	Philips
"DVDRW424"	RICOH_MP5125	Philips
"DVDRW6002"	RICOH_MP5125	Philips
"DVDRW6003"	RICOH_MP5125	Philips
"DVD6002"	RICOH_MP5125	Philips
"DVD6003"	RICOH_MP5125	Philips
"DVD+RW-D28"	RICOH_MP5125	Philips
"DVD+RW-D38"	RICOH_MP5125	Philips
"DVDRW4216INP-A"	RICOH_MP5125	lomega
"DVD+RW ND-1100A"	RICOH_MP5125	NEC
"DVRW2412PRO"	RICOH_MP5125	A-Open
"DRW4410"	RICOH_MP5125	A-Open
"DRW4416"	RICOH_MP5125	A-Open
"DVD+R/RW 2.4x8AA"	RICOH_MP5125	Memorex
"DW-7801TE"	RICOH_MP5125	Mitsumi
"DVDRW420N"	RICOH_MP5125	TDK
"DVD+RW MP5240"	RICOH_MP5240	Ricoh

"DVD+RW RW5240" RICOH\_MP5240 Ricoh  
 "MP5240A" RICOH\_MP5240 Ricoh  
 "MP5240A24" RICOH\_MP5240 Ricoh  
 "RW5240A" RICOH\_MP5240 Ricoh  
 "DVDR PX-504A" RICOH\_MP5240 Plextor  
 "DVD+RW MP8160" RICOH\_MP8160 Ricoh  
 "DVD+RW RW8160" RICOH\_MP8160 Ricoh  
 "DVD+RW SR-P08B" RICOH\_MP8160 Samsung  
 "DVDRW DDW-081" RICOH\_MP8160 QSI  
 "DVD+RW-D48" RICOH\_MP8160 Philips  
 "DVD+RW-S44" RICOH\_MP8160 Philips  
 "DVDRW416" RICOH\_MP8160 Philips  
 "DVDRW428" RICOH\_MP8160 Philips  
 "DVDRW448" RICOH\_MP8160 Philips  
 "DVD8301" RICOH\_MP8160 Philips  
 "DVDRW8301" RICOH\_MP8160 Philips  
 "LTR-0841" SANYO\_CDRW8432 Lite-On  
 "CD-RW CRX0811" SANYO\_CDRW8432 Sony  
 "CRD-BP900F" SANYO\_CDRW12432 Sanyo  
 "CRD-BP900P" SANYO\_CDRW12432 Sanyo  
 "CRD-BP900U" SANYO\_CDRW12432 Sanyo  
 "ZIPCDINT1536" SANYO\_CDRW12432 Iomega  
 "CDBP-12432A" SANYO\_CDRW12432 Lacie  
 "CRD-BP1300P" SANYO\_CDRW121032 Sanyo  
 "CD-Writer cd12i" SANYO\_CDRW121032 Hewlett Packard  
 "CD-RW RW1210E" SANYO\_CDRW121032 Creative Labs  
 "ZIPCD3840INT" SANYO\_CDRW121032 Iomega  
 "ZIPCD3840INT-E" SANYO\_CDRW121032 Iomega  
 "CDBP-121032A" SANYO\_CDRW121032 Lacie  
 "Twelve MAXX 1032" SANYO\_CDRW121032 Memorex  
 "MCD-RW12-1032" SANYO\_CDRW121032 Maxell  
 "TRUECOPY12A" SANYO\_CDRW121032 R-Quest  
 "CD-Writer cd12d" SANYO\_CDRW121032 Hewlett Packard  
 "CDR-1232DD" SANYO\_CDRW121032 Lite-On  
 "CDR-1232M" SANYO\_CDRW121032 Lite-On  
 "CDR-1232MC" SANYO\_CDRW121032 Lite-On  
 "CDR-1232S" SANYO\_CDRW121032 Lite-On  
 "LTR-12101B" SANYO\_CDRW121032 Lite-On  
 "LTR-12101C" SANYO\_CDRW121032 Lite-On  
 "LTR-12102B" SANYO\_CDRW121032 Lite-On  
 "LTR-12102C" SANYO\_CDRW121032 Lite-On  
 "CDRW121032plus" SANYO\_CDRW121032 Traxdata  
 "CRD-BP1400P" SANYO\_CDRW161040 Sanyo  
 "CD-RW CRX1611" SANYO\_CDRW161040 Sony  
 "CDRW161040B" SANYO\_CDRW161040 Generic  
 "CDRW161040X" SANYO\_CDRW161040 TDK  
 "CDRW161040XA" SANYO\_CDRW161040 TDK  
 "CDBP-161040A" SANYO\_CDRW161040 Lacie  
 "T-REX-EIDE" SANYO\_CDRW161040 Waitec  
 "SixteenMAXX 1040" SANYO\_CDRW161040 Memorex  
 "16MAXX 1040JB" SANYO\_CDRW161040 Memorex  
 "MCD-RW16-1040-L" SANYO\_CDRW161040 Maxell  
 "CDRW161040plus" SANYO\_CDRW161040 Traxdata  
 "CDRW6400INT-A" SANYO\_CDRW161040 Iomega  
 "CDRW6400INT-B" SANYO\_CDRW161040 Iomega  
 "CDRW6402EXT-B" SANYO\_CDRW161040 Iomega  
 "TRUECOPY16A" SANYO\_CDRW161040 R-Quest

"CD-Writer cd16d" SANYO\_CDRW161040 Hewlett Packard  
"CD-Writer cd16r" SANYO\_CDRW161040 Hewlett Packard  
"CDR-1640MB" SANYO\_CDRW161040 Lite-On  
"CDR-1640MC" SANYO\_CDRW161040 Lite-On  
"CDR-1640MM" SANYO\_CDRW161040 Lite-On  
"CDR-1640SB" SANYO\_CDRW161040 Lite-On  
"LTR-16101B" SANYO\_CDRW161040 Lite-On  
"LTR-16101C" SANYO\_CDRW161040 Lite-On  
"LTR-16102B" SANYO\_CDRW161040 Lite-On  
"LTR-16102C" SANYO\_CDRW161040 Lite-On  
"16X CD-RW DRIVE" SANYO\_CDRW161040 Generic  
"CDR-2040MC" SANYO\_CDRW201040 Lite-On  
"CDR-2040MM" SANYO\_CDRW201040 Lite-On  
"CRD-BP1500P" SANYO\_CDRW241040 Sanyo  
"CRD-BP1500U" SANYO\_CDRW241040 Sanyo  
"CD-RW CRX175A1" SANYO\_CDRW241040 Sony  
"CD-RW CRX2411" SANYO\_CDRW241040 Sony  
"CDRW241040B" SANYO\_CDRW241040 TDK  
"CDRW241040X" SANYO\_CDRW241040 TDK  
"CDRW241040UEX" SANYO\_CDRW241040 TDK  
"CD-RW RW2410E" SANYO\_CDRW241040 Creative Labs  
"CDBP-241040A" SANYO\_CDRW241040 Lacie  
"24MAXX 1040" SANYO\_CDRW241040 Memorex  
"MCD-RW24-1040-L" SANYO\_CDRW241040 Maxell  
"CDRW9600INT-B" SANYO\_CDRW241040 Iomega  
"CDRW9602EXT-B" SANYO\_CDRW241040 Iomega  
"CDRW9602EXT3-B" SANYO\_CDRW241040 Iomega  
"VBT241040A" SANYO\_CDRW241040 Verbatim  
"241040AL" SANYO\_CDRW241040 Verbatim/Cendyne  
"MEGALUS/1" SANYO\_CDRW241040 Waitec  
"TRUECOPY24A" SANYO\_CDRW241040 R-Quest  
"IMW241040IA" SANYO\_CDRW241040 Imation  
"CRW-2410A" SANYO\_CDRW241040 ASUS  
"CRW-2410S" SANYO\_CDRW241040 ASUS  
"CDR-2440DH" SANYO\_CDRW241040 Lite-On  
"CDR-2440DS" SANYO\_CDRW241040 Lite-On  
"CDR-2440MB" SANYO\_CDRW241040 Lite-On  
"CDR-2440MM" SANYO\_CDRW241040 Lite-On  
"CDR-2440SD" SANYO\_CDRW241040 Lite-On  
"LTR-24101B" SANYO\_CDRW241040 Lite-On  
"LTR-24101C" SANYO\_CDRW241040 Lite-On  
"LTR-24102B" SANYO\_CDRW241040 Lite-On  
"LTR-24102C" SANYO\_CDRW241040 Lite-On  
"LTR-24102M" SANYO\_CDRW241040 Lite-On  
"LTR-24102S" SANYO\_CDRW241040 Lite-On  
"LTR-24102U" SANYO\_CDRW241040 Lite-On  
"LTR-24103S" SANYO\_CDRW241040 Lite-On  
"LXR-24101A" SANYO\_CDRW241040 Lite-On  
"LXR-24101B" SANYO\_CDRW241040 Lite-On  
"LXR-24102" SANYO\_CDRW241040 Lite-On  
"LXR-24102S" SANYO\_CDRW241040 Lite-On  
"LXR-24102U" SANYO\_CDRW241040 Lite-On  
"LXR-24103" SANYO\_CDRW241040 Lite-On  
"LXR-24163" SANYO\_CDRW241040 Lite-On  
"CD-RW 24X10X40" SANYO\_CDRW241040 Acer  
"CD-R/RW 24X10X40" SANYO\_CDRW241040 Acer  
"24X CD-RW DRIVE" SANYO\_CDRW241040 Polaroid

"SMART CLONE24" SANYO\_CDRW241040 Generic  
"SMART-CLONE2440" SANYO\_CDRW241040 Generic  
"CDRW241032FPX" SANYO\_CDRW241040 Generic  
"CDRW241032UPX" SANYO\_CDRW241040 Generic  
"CDRW241040FPX" SANYO\_CDRW241040 Generic  
"CXR-1X24" SANYO\_CDRW241040 Generic  
"CXR-2X24" SANYO\_CDRW241040 Generic  
"CXR-3X24" SANYO\_CDRW241040 Generic  
"CXR-2440B" SANYO\_CDRW241040 Generic  
"CXR-2440S" SANYO\_CDRW241040 Generic  
"COMBI LSC-24081" SANYO\_CDRW241040 Generic  
"COMBI LSC-24081S" SANYO\_CDRW241040 Generic  
"COMBI LSC-24101" SANYO\_CDRW241040 Generic  
"COMBI LSC-24101S" SANYO\_CDRW241040 Generic  
"COMBI LSC-24121" SANYO\_CDRW241040 Generic  
"COMBI LSC-24121S" SANYO\_CDRW241040 Generic  
"COMBO LSC-24081" SANYO\_CDRW241040 Generic  
"COMBO LSC-24081M" SANYO\_CDRW241040 Generic  
"COMBO LSC-24081S" SANYO\_CDRW241040 Generic  
"COMBO LSC-24082" SANYO\_CDRW241040 Generic  
"COMBO LSC-24082K" SANYO\_CDRW241040 Generic  
"COMBO LSC-24082M" SANYO\_CDRW241040 Generic  
"COMBO LSC-24082S" SANYO\_CDRW241040 Generic  
"COMBO LSC-24101" SANYO\_CDRW241040 Generic  
"COMBO LSC-24101S" SANYO\_CDRW241040 Generic  
"COMBO LSC-24121" SANYO\_CDRW241040 Generic  
"COMBO LSC-24121S" SANYO\_CDRW241040 Generic  
"LSC-24081MX" SANYO\_CDRW241040 Generic  
"LSC-24081X" SANYO\_CDRW241040 Generic  
"LSC-24082KX" SANYO\_CDRW241040 Generic  
"DGM-241040" SANYO\_CDRW241040 Generic  
"XJ-SC241" SANYO\_CDRW241040 Generic  
"XJ-SC241M" SANYO\_CDRW241040 Generic  
"XJ-SC242K" SANYO\_CDRW241040 Generic  
"XJ-SC242M" SANYO\_CDRW241040 Generic  
"XJ-SC242S" SANYO\_CDRW241040 Generic  
"CBRW2B-24X" SANYO\_CDRW241040 Generic  
"CBXRW-24X" SANYO\_CDRW241040 Generic  
"CLW-224A" SANYO\_CDRW241040 Generic  
"CRD-BP1600P" SANYO\_CDRW321040 Sanyo  
"QPSCRD-BP1600P" SANYO\_CDRW321040 QPS  
"CD-RW CRX185E1" SANYO\_CDRW321040 Sony  
"CD-RW CRX185E2" SANYO\_CDRW321040 Sony  
"CD-RW CRX185E3" SANYO\_CDRW321040 Sony  
"CDRW321040B" SANYO\_CDRW321040 TDK  
"CDRW321040X" SANYO\_CDRW321040 TDK  
"CDRW321240B" SANYO\_CDRW321040 TDK  
"CDRW321240X" SANYO\_CDRW321040 TDK  
"CD-RW RW3210E" SANYO\_CDRW321040 Creative Labs  
"CDBP-321040A" SANYO\_CDRW321040 Lacie  
"CDBP-321240A" SANYO\_CDRW321040 Lacie  
"32MAXX 1240AJ" SANYO\_CDRW321040 Memorex  
"32MAXX 1240AK" SANYO\_CDRW321040 Memorex  
"CDRW15360INT-B" SANYO\_CDRW321040 Iomega  
"CDRW15362EXT3-B" SANYO\_CDRW321040 Iomega  
"VBT321040A" SANYO\_CDRW321040 Verbatim  
"321240AL" SANYO\_CDRW321040 Verbatim/Cendyne

"STORM32" SANYO\_CDRW321040 Waitec  
"FREecom32A" SANYO\_CDRW321040 Freecom  
"LTR-32102H" SANYO\_CDRW321040 Lite-On  
"LTR-32102S" SANYO\_CDRW321040 Lite-On  
"LTR-32103S" SANYO\_CDRW321040 Lite-On  
"LTR-32105S" SANYO\_CDRW321040 Lite-On  
"LTR-32123H" SANYO\_CDRW321040 Lite-On  
"LTR-32123S" SANYO\_CDRW321040 Lite-On  
"LTR-32125K" SANYO\_CDRW321040 Lite-On  
"LTR-32125M" SANYO\_CDRW321040 Lite-On  
"LTR-32125S" SANYO\_CDRW321040 Lite-On  
"LTR-32125W" SANYO\_CDRW321040 Lite-On  
"LXR-322" SANYO\_CDRW321040 Lite-On  
"LXR-323" SANYO\_CDRW321040 Lite-On  
"LXR-32122" SANYO\_CDRW321040 Lite-On  
"LXR-32122A" SANYO\_CDRW321040 Lite-On  
"LXR-32122B" SANYO\_CDRW321040 Lite-On  
"LXR-32122C" SANYO\_CDRW321040 Lite-On  
"LXR-32122S" SANYO\_CDRW321040 Lite-On  
"LXR-32123" SANYO\_CDRW321040 Lite-On  
"LXR-32125" SANYO\_CDRW321040 Lite-On  
"JLR-3240H" SANYO\_CDRW321040 Lite-On  
"CDR-3240MH" SANYO\_CDRW321040 Lite-On  
"CDR-3240MS" SANYO\_CDRW321040 Lite-On  
"CDR-3240S" SANYO\_CDRW321040 Lite-On  
"CDR-3240WD" SANYO\_CDRW321040 Lite-On  
"LTR-3248MH" SANYO\_CDRW321040 Lite-On  
"CDR-3248MS" SANYO\_CDRW321040 Lite-On  
"MAR-321040S" SANYO\_CDRW321040 Lite-On  
"MAR-321040SD" SANYO\_CDRW321040 Lite-On  
"CD-RW 32X10X40" SANYO\_CDRW321040 Acer  
"CD-RW 32X12X40" SANYO\_CDRW321040 Acer  
"COMBO 32X12" SANYO\_CDRW321040 Acer  
"32X CD-RW DRIVE" SANYO\_CDRW321040 Polaroid  
"SMART CLONE32" SANYO\_CDRW321040 Generic  
"SMART-CLONE3240" SANYO\_CDRW321040 Generic  
"CDR-5S32" SANYO\_CDRW321040 Generic  
"CDR-5K32" SANYO\_CDRW321040 Generic  
"CDR-5W32" SANYO\_CDRW321040 Generic  
"CDR-6S32" SANYO\_CDRW321040 Generic  
"CXR-2X32" SANYO\_CDRW321040 Generic  
"CXR-3X32" SANYO\_CDRW321040 Generic  
"CXR-3240" SANYO\_CDRW321040 Generic  
"CXR-3240A" SANYO\_CDRW321040 Generic  
"CXR-3240B" SANYO\_CDRW321040 Generic  
"CXR-3240C" SANYO\_CDRW321040 Generic  
"CXR-3240S" SANYO\_CDRW321040 Generic  
"DGM-321240" SANYO\_CDRW321040 Generic  
"RWJ-321S" SANYO\_CDRW321040 Generic  
"CBRW3S-32X" SANYO\_CDRW321040 Generic  
"CBRW5S-32X" SANYO\_CDRW321040 Generic  
"CBRW6S-32X" SANYO\_CDRW321040 Generic  
"CLW-232A" SANYO\_CDRW321040 Generic  
"CRD-BP1700P" SANYO\_CDRW401248 Sanyo  
"CRD-BP1700U" SANYO\_CDRW401248 Sanyo  
"CRD-BPI1700P" SANYO\_CDRW401248 QPS  
"CRD-BPO1700P" SANYO\_CDRW401248 QPS

"QPSCRD-BP1700P" SANYO\_CDRW401248 QPS  
"CD-RW CRX195E1" SANYO\_CDRW401248 Sony  
"CDRW401240B" SANYO\_CDRW401248 TDK  
"CDRW401240X" SANYO\_CDRW401248 TDK  
"CDRW401248B" SANYO\_CDRW401248 TDK  
"CDRW401248UEX" SANYO\_CDRW401248 TDK  
"CD-RW RW4010E" SANYO\_CDRW401248 Creative Labs  
"CDBP-401240A" SANYO\_CDRW401248 Lacie  
"CDBP-401248A" SANYO\_CDRW401248 Lacie  
"40MAXX 1240AJ" SANYO\_CDRW401248 Memorex  
"40MAXX 1248AJ" SANYO\_CDRW401248 Memorex  
"40EMAX 1240AJ" SANYO\_CDRW401248 Memorex  
"40EMAX 2440AJ" SANYO\_CDRW401248 Memorex  
"MCD-RW4012-48" SANYO\_CDRW401248 Maxell  
"CDRW19202EXT2-B" SANYO\_CDRW401248 lomega  
"CDRW23040INT-B" SANYO\_CDRW401248 lomega  
"CDRW23042EXT-B" SANYO\_CDRW401248 lomega  
"CDRW38402EXT2-B" SANYO\_CDRW401248 lomega  
"MCD-RW4012-48" SANYO\_CDRW401248 Maxell  
"MCD-RW40-1248-L" SANYO\_CDRW401248 Maxell  
"401248AL" SANYO\_CDRW401248 Verbatim/Cendyne  
"STORM40" SANYO\_CDRW401248 Waitec  
"FRISBYII" SANYO\_CDRW401248 Waitec  
"FREECOM40A" SANYO\_CDRW401248 Freecom  
"IMW402440EA" SANYO\_CDRW401248 Imation  
"CDR-4048S" SANYO\_CDRW401248 Lite-On  
"CDR-4048SD" SANYO\_CDRW401248 Lite-On  
"CDR-4048W" SANYO\_CDRW401248 Lite-On  
"COB-1K4012" SANYO\_CDRW401248 Lite-On  
"LTR-40125K" SANYO\_CDRW401248 Lite-On  
"LTR-40125S" SANYO\_CDRW401248 Lite-On  
"LTR-40125W" SANYO\_CDRW401248 Lite-On  
"LTR-40126H" SANYO\_CDRW401248 Lite-On  
"LTR-40126K" SANYO\_CDRW401248 Lite-On  
"LTR-40126S" SANYO\_CDRW401248 Lite-On  
"LTR-40246S" SANYO\_CDRW401248 Lite-On  
"LXR-402" SANYO\_CDRW401248 Lite-On  
"LXR-403" SANYO\_CDRW401248 Lite-On  
"LXR-40122" SANYO\_CDRW401248 Lite-On  
"LXR-40122A" SANYO\_CDRW401248 Lite-On  
"LXR-40122B" SANYO\_CDRW401248 Lite-On  
"LXR-40122C" SANYO\_CDRW401248 Lite-On  
"LXR-40123" SANYO\_CDRW401248 Lite-On  
"LXR-40243" SANYO\_CDRW401248 Lite-On  
"MAR-401248S" SANYO\_CDRW401248 Lite-On  
"MAR-401248SD" SANYO\_CDRW401248 Lite-On  
"MAR-401248W" SANYO\_CDRW401248 Lite-On  
"CD-RW 40X12" SANYO\_CDRW401248 Acer  
"40X CD-RW DRIVE" SANYO\_CDRW401248 Polaroid  
"SMART CLONE40" SANYO\_CDRW401248 Generic  
"SMART-CLONE4048" SANYO\_CDRW401248 Generic  
"CDRW401248UEX" SANYO\_CDRW401248 Generic  
"CDR-5K40" SANYO\_CDRW401248 Generic  
"CDR-5S40" SANYO\_CDRW401248 Generic  
"CDR-5W40" SANYO\_CDRW401248 Generic  
"CDR-6K40" SANYO\_CDRW401248 Generic  
"CDR-6S40" SANYO\_CDRW401248 Generic

"DGM-401248" SANYO\_CDRW401248 Generic  
"XJ-HC401K" SANYO\_CDRW401248 Generic  
"RWJ-401S" SANYO\_CDRW401248 Generic  
"CBRW5S-40X" SANYO\_CDRW401248 Generic  
"CBRW6K-40X" SANYO\_CDRW401248 Generic  
"CBRW6S-40X" SANYO\_CDRW401248 Generic  
"CBXRW-40X" SANYO\_CDRW401248 Generic  
"CBXRW-40XB" SANYO\_CDRW401248 Generic  
"CLW-240A" SANYO\_CDRW401248 Generic  
"CRD-BP1800P" SANYO\_CDRW481648 Sanyo  
"CD-RW CRX210E1" SANYO\_CDRW481648 Sony  
"CD-RW CRX215E1" SANYO\_CDRW481648 Sony  
"CDRW4800B" SANYO\_CDRW481648 TDK  
"CDRW4800X" SANYO\_CDRW481648 TDK  
"CDRW481248B" SANYO\_CDRW481648 TDK  
"CDRW482448B" SANYO\_CDRW481648 TDK  
"CD-RW RW4810E" SANYO\_CDRW481648 Creative Labs  
"CD-RW RW4811E" SANYO\_CDRW481648 Creative Labs  
"48MAXX 1248AJ" SANYO\_CDRW481648 Memorex  
"48MAXX 2448AJ" SANYO\_CDRW481648 Memorex  
"48MAX 244816AJ" SANYO\_CDRW481648 Memorex  
"MCD-RW4812-48" SANYO\_CDRW481648 Maxell  
"MCD-RW4824-48" SANYO\_CDRW481648 Maxell  
"CDRW55296INT-B" SANYO\_CDRW481648 Iomega  
"CDRW55292EXT3-B" SANYO\_CDRW481648 Iomega  
"481248AL" SANYO\_CDRW481648 Verbatim/Cendyne  
"481648AL" SANYO\_CDRW481648 Verbatim/Cendyne  
"482448AL" SANYO\_CDRW481648 Verbatim/Cendyne  
"IMW482448DV81AC" SANYO\_CDRW481648 Imation  
"CDR-4848S" SANYO\_CDRW481648 Lite-On  
"COB-1K4816" SANYO\_CDRW481648 Lite-On  
"COB-1H4816" SANYO\_CDRW481648 Lite-On  
"LTC-48161" SANYO\_CDRW481648 Lite-On  
"LTC-48161H" SANYO\_CDRW481648 Lite-On  
"LTC-48161K" SANYO\_CDRW481648 Lite-On  
"COMBO LTC-48161H" SANYO\_CDRW481648 Lite-On  
"COMBO LTC-48161K" SANYO\_CDRW481648 Lite-On  
"LTR-48125G" SANYO\_CDRW481648 Lite-On  
"LTR-48125S" SANYO\_CDRW481648 Lite-On  
"LTR-48125W" SANYO\_CDRW481648 Lite-On  
"LTR-48126S" SANYO\_CDRW481648 Lite-On  
"LTR-48166K" SANYO\_CDRW481648 Lite-On  
"LTR-48166S" SANYO\_CDRW481648 Lite-On  
"LTR-48246K" SANYO\_CDRW481648 Lite-On  
"LTR-48246S" SANYO\_CDRW481648 Lite-On  
"LTR-48247S" SANYO\_CDRW481648 Lite-On  
"LTR-48327K" SANYO\_CDRW481648 Lite-On  
"LTR-48327S" SANYO\_CDRW481648 Lite-On  
"CD-RW 48X12" SANYO\_CDRW481648 Acer  
"CD-RW 48X16" SANYO\_CDRW481648 Acer  
"CD-RW 48X20" SANYO\_CDRW481648 Acer  
"CD-RW 48X24" SANYO\_CDRW481648 Acer  
"CDRW 48X16" SANYO\_CDRW481648 Acer  
"CDRW 48X24" SANYO\_CDRW481648 Acer  
"CDRW DRIVE 48X16" SANYO\_CDRW481648 Acer  
"CDRW DRIVE 48X24" SANYO\_CDRW481648 Acer  
"COMBO 48X24" SANYO\_CDRW481648 Acer

"48X CD-RW DRIVE" SANYO\_CDRW481648 Polaroid  
"CD-RW CW5203" SANYO\_CDRW481648 OptoRite  
"R/RW 48xB" SANYO\_CDRW481648 Philips  
"CDRW48P" SANYO\_CDRW481648 Philips  
"PBRW4824" SANYO\_CDRW481648 Philips  
"CDR-5G48" SANYO\_CDRW481648 Generic  
"CDR-5S48" SANYO\_CDRW481648 Generic  
"CDR-5W48" SANYO\_CDRW481648 Generic  
"CDR-6K48" SANYO\_CDRW481648 Generic  
"CDR-6S48" SANYO\_CDRW481648 Generic  
"CDR-7K48" SANYO\_CDRW481648 Generic  
"CDR-7S48" SANYO\_CDRW481648 Generic  
"CDRW48P" SANYO\_CDRW481648 Generic  
"CDRW 482448A" SANYO\_CDRW481648 Generic  
"CD-RW 48/24/48X" SANYO\_CDRW481648 Generic  
"DGM-481248" SANYO\_CDRW481648 Generic  
"DGM-482448" SANYO\_CDRW481648 Generic  
"XJ-HC481K" SANYO\_CDRW481648 Generic  
"RWJ-481S" SANYO\_CDRW481648 Generic  
"RWJ-482S" SANYO\_CDRW481648 Generic  
"RWJ-483S" SANYO\_CDRW481648 Generic  
"CBCO1H-48X" SANYO\_CDRW481648 Generic  
"CBCO1K-48X" SANYO\_CDRW481648 Generic  
"CBRW6S-48X" SANYO\_CDRW481648 Generic  
"CBRW7K-48X" SANYO\_CDRW481648 Generic  
"CBRW7S-48X" SANYO\_CDRW481648 Generic  
"CRD-BP1900P" SANYO\_CDRW522452 Sanyo  
"CD-RW CRX220E1" SANYO\_CDRW522452 Sony  
"CD-RW CRX225E1" SANYO\_CDRW522452 Sony  
"CDRW5200B" SANYO\_CDRW522452 TDK  
"CDRW5201B" SANYO\_CDRW522452 TDK  
"CDRW523252B" SANYO\_CDRW522452 TDK  
"52MAXX 3252AJ" SANYO\_CDRW522452 Memorex  
"52MAXX 2452AJ" SANYO\_CDRW522452 Memorex  
"MCD-RW5224-52" SANYO\_CDRW522452 Maxell  
"MCD-RW5232-52" SANYO\_CDRW522452 Maxell  
"CDRW64896INT-B" SANYO\_CDRW522452 Iomega  
"CDRW64892EXT3-C" SANYO\_CDRW522452 Iomega  
"522452AL" SANYO\_CDRW522452 Verbatim/Cendyne  
"523252AL" SANYO\_CDRW522452 Verbatim/Cendyne  
"LTR-52246S" SANYO\_CDRW522452 Lite-On  
"LTR-52247S" SANYO\_CDRW522452 Lite-On  
"LTR-52326K" SANYO\_CDRW522452 Lite-On  
"LTR-52326S" SANYO\_CDRW522452 Lite-On  
"LTR-52327K" SANYO\_CDRW522452 Lite-On  
"LTR-52327S" SANYO\_CDRW522452 Lite-On  
"CD-RW 50X16" SANYO\_CDRW522452 Acer  
"CD-RW 50X20" SANYO\_CDRW522452 Acer  
"CD-RW 52X20" SANYO\_CDRW522452 Acer  
"CD-RW 52X24" SANYO\_CDRW522452 Acer  
"CD-RW 52X32" SANYO\_CDRW522452 Acer  
"CDRW 52X24" SANYO\_CDRW522452 Acer  
"CDRW 52X32" SANYO\_CDRW522452 Acer  
"CDRW DRIVE 52X24" SANYO\_CDRW522452 Acer  
"CDRW DRIVE 52X32" SANYO\_CDRW522452 Acer  
"COMBO 52X24" SANYO\_CDRW522452 Acer  
"COMBO 52X32" SANYO\_CDRW522452 Acer

"STORM52/1" SANYO\_CDRW522452 Waitec  
 "CD-RW CW5201" SANYO\_CDRW522452 OptoRite  
 "CD-RW CW5202" SANYO\_CDRW522452 OptoRite  
 "CD-RW CW5205" SANYO\_CDRW522452 OptoRite  
 "CD-RW MS8352" SANYO\_CDRW522452 MSI  
 "CD-RW MS8352S" SANYO\_CDRW522452 MSI  
 "CDRW522452plus" SANYO\_CDRW522452 Traxdata  
 "CDRW52P" SANYO\_CDRW522452 Philips  
 "PBRW5224" SANYO\_CDRW522452 Philips  
 "CDR-6K52" SANYO\_CDRW522452 Generic  
 "CDR-6S52" SANYO\_CDRW522452 Generic  
 "CDR-7K52" SANYO\_CDRW522452 Generic  
 "CDR-7S52" SANYO\_CDRW522452 Generic  
 "CDRW 522452A" SANYO\_CDRW522452 Generic  
 "CDRW 523252A" SANYO\_CDRW522452 Generic  
 "CD-RW 52/24/52X" SANYO\_CDRW522452 Generic  
 "CD-RW 52/32/52X" SANYO\_CDRW522452 Generic  
 "LRW-5224L" SANYO\_CDRW522452 Generic  
 "CBRW6K-52X" SANYO\_CDRW522452 Generic  
 "CBRW6S-52X" SANYO\_CDRW522452 Generic  
 "CBRW7K-52X" SANYO\_CDRW522452 Generic  
 "CBRW7S-52X" SANYO\_CDRW522452 Generic  
 "CD-RW CRX100E" SONY\_CRX100 Sony  
 "CD-RW CRX10U" SONY\_CRX100 Sony  
 "CD-Writer+ 8100" SONY\_CRX100 Hewlett Packard  
 "CD-R CRX110E" SONY\_CRX110 Sony  
 "CD-Writer+ 7500" SONY\_CRX120\_2X Hewlett Packard  
 "CD-RW CRX120E" SONY\_CRX120\_4X Sony  
 "CD-RW CRX500E" SONY\_CRX120\_4X Sony  
 "CD-R CRX510E" SONY\_CRX120\_4X Sony  
 "CD-Writer+ 8200" SONY\_CRX120\_4X Hewlett Packard  
 "CD-R/RW ECW-043" SONY\_CRX120\_4X QSI  
 "CRS446U" SONY\_CRX120\_4X A-Open  
 "CD-RW CRX130E" SONY\_CRX130 Sony  
 "CD-Writer+ 8200a" SONY\_CRX130 Hewlett Packard  
 "CD-RW CRX140E" SONY\_CRX140 Sony  
 "CD-RW CRX700E" SONY\_CRX140 Sony  
 "CD-RW CRX800E" SONY\_CRX140 Sony  
 "CD-RW CRX75A" SONY\_CRX140 Sony  
 "CD-Writer+ 9100" SONY\_CRX140 Hewlett Packard  
 "NR-7500A" SONY\_CRX140 NEC  
 "BCE833IE" SONY\_CRX140 BTC  
 "CD-RW CRX145E" SONY\_CRX145 Sony  
 "CD-RW CRX145RP" SONY\_CRX145 Sony  
 "CD-Writer+ 9300" SONY\_CRX145 Hewlett Packard  
 "BCE1032IE" SONY\_CRX145 BTC  
 "CD-RW CRX160E" SONY\_CRX160 Sony  
 "CD-RW CRX200E" SONY\_CRX160 Sony  
 "CD-Writer+ 9500" SONY\_CRX160 Hewlett Packard  
 "BCE128IE" SONY\_CRX160 BTC  
 "CD-RW CRX168B" SONY\_CRX168 Sony  
 "CD-RW CRX810E" SONY\_CRX168 Sony  
 "CD-RW CRX85A" SONY\_CRX85 Sony  
 "CD-RW CRX85MA" SONY\_CRX85 Sony  
 "CD-RW CRX85U" SONY\_CRX85 Sony  
 "CD-RW CRX175A" SONY\_CRX175 Sony  
 "CD-RW CRX175E" SONY\_CRX175 Sony

"CD-RW CRX820E"	SONY_CRX175	Sony
"CD-RW CRX20MU"	SONY_CRX175	Sony
"FREECOM24C"	SONY_CRX175	Freecom
"CD-RW CRX185A"	SONY_CRX185	Sony
"CD-RW CRX185E"	SONY_CRX185	Sony
"CD-RW CRX185M"	SONY_CRX185	Sony
"CD-RW CRX195A"	SONY_CRX195	Sony
"CD-RW CRX195E"	SONY_CRX195	Sony
"DVD RW DRU-500A"	SONY_DRU500	Sony
"DVD RW DRU-510A"	SONY_DRU500	Sony
"DVD RW DW-U10A"	SONY_DRU500	Sony
"DVD RW DW-U12A"	SONY_DRU500	Sony
"DVD RW DW-U14A"	SONY_DRU500	Sony
"DVD+R/RW 4412AJ"	SONY_DRU500	Memorex
"DVDRW LDW-400D"	SONY_DRU500	Lite-On
"DVDRW LDW-401D"	SONY_DRU500	Lite-On
"DVD_RW ND-1200A"	SONY_DRU500	NEC
"DVD_RW ND-1300A"	SONY_DRU500	NEC
"DVD RW GCA-4040N"	SONY_DRU500	LG Electronics
"DVD+RW GCA-4040N"	SONY_DRU500	LG Electronics
"DVD-RW DVR-106"	SONY_DRU500	Pioneer
"DVD-MULTI SRT08B"	SONY_DRU500	Samsung
"DVD+RW SN-W08B"	SONY_DRU500	Samsung
"DW-7802TE"	SONY_DRU500	Mitsumi
"DVDRW LDW-421S"	SONY_DRU500	Lite-On
"DVDRW0400N"	SONY_DRU500	Generic
"DVDRW0404N"	SONY_DRU500	Generic
"DVDRW0404UFN"	SONY_DRU500	Generic
"DRW1004IM"	SONY_DRU500	BTC
"DRW1008IM"	SONY_DRU500	BTC
"DRW1012IM"	SONY_DRU500	BTC
"CD-W24E"	TEAC_CDW54	Teac
"CD-W54E"	TEAC_CDW54	Teac
"CD-REWRITER-4H"	TEAC_CDW54	Micro Solutions
"CD-REWRITER-4G"	TEAC_CDW54	Micro Solutions
"CD-W28E"	TEAC_CDW58	Teac
"CD-W58E"	TEAC_CDW58	Teac
"DW-28E"	TEAC_CDW58	Teac
"CD-REWRITER-8B"	TEAC_CDW58	Micro Solutions
"CD-W512E"	TEAC_CDW512	Teac
"CD-W512EB"	TEAC_CDW512	Teac
"IMW121032A"	TEAC_CDW512	Imation
"IMW121032B"	TEAC_CDW512	Imation
"IMW121032IAB"	TEAC_CDW512	Imation
"RAPTOR RED"	TEAC_CDW512	Waitec
"CD-W216E"	TEAC_CDW516	Teac
"CD-W516E"	TEAC_CDW516	Teac
"CD-W516EB"	TEAC_CDW516	Teac
"CD-W516EC"	TEAC_CDW516	Teac
"CD-W224E"	TEAC_CDW524	Teac
"CD-W224EA"	TEAC_CDW524	Teac
"CD-W524E"	TEAC_CDW524	Teac
"DW-224E"	TEAC_CDW524	Teac
"241040AT"	TEAC_CDW524	Verbatim/Cendyne
"CD-W532E"	TEAC_CDW532	Teac
"321240AT"	TEAC_CDW532	Verbatim/Cendyne
"CD-W540E"	TEAC_CDW540	Teac

"FREECOM40F"	TEAC_CDW540	Freecom
"401248AT"	TEAC_CDW540	Verbatim/Cendyne
"CD-W548E"	TEAC_CDW548	Teac
"481248AT"	TEAC_CDW548	Verbatim/Cendyne
"CD-W552E"	TEAC_CDW552	Teac
"CD-W552EL"	TEAC_CDW552	Teac
"522452AU"	TEAC_CDW552	Verbatim/Cendyne
"523252AU"	TEAC_CDW552	Verbatim/Cendyne
"DVD-ROM SD-R1002"	TOSHIBA_SDR1002	Toshiba
"DVD-ROM SD-R2002"	TOSHIBA_SDR1002	Toshiba
"DVD-ROM SD-R1102"	TOSHIBA_SDR1102	Toshiba
"DVD-ROM SD-R2102"	TOSHIBA_SDR1102	Toshiba
"CDRW/DVD SDR2102"	TOSHIBA_SDR1102	Toshiba
"DVD-ROM SD-R1202"	TOSHIBA_SDR1202	Toshiba
"DVD-ROM SD-R2212"	TOSHIBA_SDR1202	Toshiba
"CDR401"	YAMAHA_CDR400	Yamaha
"CDR401t"	YAMAHA_CDR400	Yamaha
"CRW4001"	YAMAHA_CRW4260	Yamaha
"CDRW4001"	YAMAHA_CRW4260	Yamaha
"CRW4261"	YAMAHA_CRW4260	Yamaha
"CRW-2642"	YAMAHA_CRW4260	Memorex
"CRW-426"	YAMAHA_CRW4260	Dysan
"CRW-1426"	YAMAHA_CRW4260	Dysan
"CDRW-642"	YAMAHA_CRW4260	Wearnes
"CDRW-642e"	YAMAHA_CRW4260	Wearnes
"CDRW-1642"	YAMAHA_CRW4260	Wearnes
"CDRW-1642e"	YAMAHA_CRW4260	Wearnes
"CD-REWRITER-4A"	YAMAHA_CRW4260	Micro Solutions
"JCD-1642RW"	YAMAHA_CRW4260	JCCOM
"JCD-64RW"	YAMAHA_CRW4260	JCCOM
"CRW2216E"	YAMAHA_CRW2216	Yamaha
"CDRW-2216"	YAMAHA_CRW2216	Memorex
"CDRW-1622"	YAMAHA_CRW2216	Wearnes
"CDRW-1622e"	YAMAHA_CRW2216	Wearnes
"JCD-1622RW"	YAMAHA_CRW2216	JCCOM
"CRW4416E"	YAMAHA_CRW4416	Yamaha
"CDRW-4416"	YAMAHA_CRW4416	Memorex
"PCA460RW"	YAMAHA_CRW4416	Philips
"CDRW-1688"	YAMAHA_CRW4416	Wearnes
"CRW8424E"	YAMAHA_CRW8424	Yamaha
"CRW8824E"	YAMAHA_CRW8424	Yamaha
"CRW2100E"	YAMAHA_CRW2100	Yamaha
"CRW2100IX"	YAMAHA_CRW2100	Yamaha
"CD-Writer+ 9700K"	YAMAHA_CRW2100	Hewlett Packard
"CRW2200E"	YAMAHA_CRW2200	Yamaha
"CRW2200IX"	YAMAHA_CRW2200	Yamaha
"CRW2200UX"	YAMAHA_CRW2200	Yamaha
"CRW3200E"	YAMAHA_CRW3200	Yamaha
"CD-RW CRW3200EZ"	YAMAHA_CRW3200	Yamaha
"CD-RW SW-224PS"	YAMAHA_CRW3200	Samsung
"FREECOM24E"	YAMAHA_CRW3200	Freecom
"STORM24"	YAMAHA_CRW3200	Waitec
"R/RW 24x10A"	YAMAHA_CRW3200	Generic
"R/RW 24x12A"	YAMAHA_CRW3200	Generic
"CRW-F1E"	YAMAHA_CRWF1	Yamaha
"STORM48/2"	YAMAHA_CRWF1	Yamaha
"CRW-70"	YAMAHA_CRW70	Yamaha

## SCSI Recorders:

"CD-Writer 6020"	HP_6020	Hewlett Packard
"XR-W2001"	JVC_XRW2001	JVC
"RCD-1000"	JVC_XRW2001	Pinnacle
"RCD5020"	JVC_XRW2001	Pinnacle
"XR-W2010"	JVC_XRW2010	JVC
"RCD5040"	JVC_XRW2010	Pinnacle
"XR-W2020"	JVC_XRW2020	JVC
"R2626"	JVC_XRW2020	JVC
"RCD5060"	JVC_XRW2020	Pinnacle
"CD-R2006PLUS"	JVC_XRW2020	Smart & Friendly
"XR-W2040"	JVC_XRW2040	JVC
"XR-W2042"	JVC_XRW2040	JVC
"CD-RW226"	JVC_XRW2040	Smart & Friendly
"XR-W4080S"	JVC_XRW4080	JVC
"XR-W4082S"	JVC_XRW4080	JVC
"CD-RW4224S"	JVC_XRW4080	Smart & Friendly
"CD-RW4424S"	JVC_XRW4080	Smart & Friendly
"KHSW/OB-01"	KODAK_PCD600	Kodak
"CD-R CW-7501"	MATSHITA_CW7501	Matsushita
"CD-R LK-MW602"	MATSHITA_CW7501	Matsushita
"CDR4210"	MATSHITA_CW7501	Creative Labs
"CDR4240"	MATSHITA_CW7501	Plasmon
"CD-R CW-7502"	MATSHITA_CW7502	Matsushita
"CD-R CW-7503"	MATSHITA_CW7503	Matsushita
"CDD521/10"	PHILIPS_CDD521	Philips
"CDD521/02"	PHILIPS_CDD521	Kodak
"RF4100"	PHILIPS_CDD521	Plasmon
"RF4102"	PHILIPS_CDD521	Plasmon
"CDD522/10"	PHILIPS_CDD522	Philips
"PCD225"	PHILIPS_CDD522	Kodak
"PLAYWRITE 2002"	PHILIPS_CDD522	MBI
"CDD2000"	PHILIPS_CDD2000	Philips
"CDD2000/00"	PHILIPS_CDD2000	Philips
"CDD2000/09"	PHILIPS_CDD2000	Philips
"CDR4220"	PHILIPS_CDD2000	Plasmon
"C4324/C4325"	PHILIPS_CDD2000	Hewlett Packard
"CDR100IPW"	PHILIPS_CDD2000	Grundig
"CD-R CR-2401TS"	PHILIPS_CDD2000	Mitsumi
"CDR-432"	PHILIPS_CDD2000	Wearnes
"CD-R2000"	PHILIPS_CDD2000	Hightech
"CDR-240"	PHILIPS_CDD2000	Kodak
"CRD-R24S"	PHILIPS_CDD2000	Sanyo
"CD-WO EW-50"	PHILIPS_CDD2000	Taiyo Yuden
"CDVR-2X4"	PHILIPS_CDD2000	Mitsubishi
"CDD2600"	PHILIPS_CDD2600	Philips
"CDD2600/00"	PHILIPS_CDD2600	Philips
"CDD2600/01"	PHILIPS_CDD2600	Philips
"CD-R CR-2601TS"	PHILIPS_CDD2600	Mitsumi
"CDR-632P"	PHILIPS_CDD2600	Wearnes
"CDVR2X6"	PHILIPS_CDD2600	Mitsubishi
"CDD3600"	PHILIPS_CDD3600	Philips
"CDD3600 CD-R/RW"	PHILIPS_CDD3600	Philips
"WT2036"	PHILIPS_CDD3600	Waitec

"CRW2260 PRO" PHILIPS\_CDD3600 Traxdata  
 "CDRW3210S" PHILIPS\_CDRW3210 Philips  
 "CDRWDVD3210S" PHILIPS\_CDRW3210 Philips  
 "CD-WO DW-S114X" PIONEER\_DWS114X Pioneer  
 "CD-WO DR-R504X" PIONEER\_DWS114X Pioneer  
 "DVD-RW DVR-303" PIONEER\_DVR103 Pioneer  
 "CD-R PX-R412C" PLEXTOR\_PXR412 Plextor  
 "CD-R PX-W4220T" PLEXTOR\_PXW4220 Plextor  
 "CD-R PX-R820T" PLEXTOR\_PXR820 Plextor  
 "CD-R 8x/20x" PLEXTOR\_PXR820 Hewlett Packard  
 "CD-R IMR080020" PLEXTOR\_PXR820 Imation  
 "CD-R PX-W8220T" PLEXTOR\_PXW8220 Plextor  
 "CD-R WT2082" PLEXTOR\_PXW8220 Waitec  
 "CD-RW IMW080220" PLEXTOR\_PXW8220 Imation  
 "CD-R PX-W124TS" PLEXTOR\_PXW124 Plextor  
 "CDRW-12432S" PLEXTOR\_PXW124 Lacie  
 "CD-R PX-W1210S" PLEXTOR\_PXW1210 Plextor  
 "CD-R PX-W1610S" PLEXTOR\_PXW1610 Plextor  
 "CD-R PX-W2410S" PLEXTOR\_PXW2410 Plextor  
 "CD-R PX-W4012S" PLEXTOR\_PXW4012 Plextor  
 "RO-1420C" RICOH\_RS1420C Ricoh  
 "CR-1420C" RICOH\_RS1420C Acer  
 "CD-R PX-R24CS" RICOH\_RS1420C Plextor  
 "MP6200S" RICOH\_MP6200S Ricoh  
 "MP6201S" RICOH\_MP6200S Ricoh  
 "OMNIWRITER26" RICOH\_MP6200S Philips  
 "CRW620" RICOH\_MP6200S Memorex  
 "RCDW226" RICOH\_MP6200S Pinnacle  
 "CDRW226" RICOH\_MP6200S Mitsubishi  
 "680RW" RICOH\_MP6200S Nomai  
 "LTR-511" RICOH\_MP6200S Lite-On  
 "CD-R/RW MP7040S" RICOH\_MP7040 Ricoh  
 "CD-R/RW RW7040S" RICOH\_MP7040 Ricoh  
 "CDRW4420s" RICOH\_MP7040 Memorex  
 "CDRW-4420s" RICOH\_MP7040 Memorex  
 "CD-R/RW MP7060S" RICOH\_MP7060 Ricoh  
 "CD-R/RW RW7060S" RICOH\_MP7060 Ricoh  
 "CDRW-6424S" RICOH\_MP7060 Memorex  
 "CD-RW6424s" RICOH\_MP7060 Smart & Friendly  
 "CD-R/RW MP7080S" RICOH\_MP7080 Ricoh  
 "CD-R/RW RW7080S" RICOH\_MP7080 Ricoh  
 "CD-R/RW MP8040S" RICOH\_MP8040 Ricoh  
 "CD-R/RW RW8040S" RICOH\_MP8040 Ricoh  
 "CD-Writer+ M820" RICOH\_MP8040 Hewlett Packard  
 "CDRRW01" RICOH\_MP8040 Matsushita  
 "CD-R CRD-R800S" SANYO\_CDR8020 Sanyo  
 "CD-R CDR-N820S" SANYO\_CDR8020 Caravell  
 "CD-R8020" SANYO\_CDR8020 Smart & Friendly  
 "CRD-RW1" SANYO\_CDRW8220 Sanyo  
 "CRD-RW1N" SANYO\_CDRW8220 Sanyo  
 "CD-RW8220" SANYO\_CDRW8220 Smart & Friendly  
 "CD-RW BOOSTER" SANYO\_CDRW8220 Lacie  
 "CDRW-BOOSTER" SANYO\_CDRW8220 Lacie  
 "CRW-8220S" SANYO\_CDRW8220 Caravell  
 "QPS-R8220S" SANYO\_CDRW8220 QPS  
 "CD-RW 8220S" SANYO\_CDRW8220 Memorex  
 "CRD-RW2" SANYO\_CDRW12432 Sanyo

"CRD-BP2"	SANYO_CDRW12432	Sanyo
"CD-RW12432"	SANYO_CDRW12432	Smart & Friendly
"CDRW-12432S"	SANYO_CDRW12432	Lacie
"CDBP-12432S"	SANYO_CDRW12432	Lacie
"LTR-1240"	SANYO_CDRW12432	Lite-On
"LTR-1240B"	SANYO_CDRW12432	Lite-On
"CRD-BP3"	SANYO_CDRW121032	Sanyo
"RAPTOR"	SANYO_CDRW121032	Waitec
"CDBP-121032S"	SANYO_CDRW121032	Lacie
"TRUECOPY12S"	SANYO_CDRW121032	R-Quest
"CRD-BP4"	SANYO_CDRW161040	Sanyo
"CDBP-161040S"	SANYO_CDRW161040	Lacie
"SMARTDRIVE4"	SANYO_CDRW161040	Mediaform
"T-REX"	SANYO_CDRW161040	Waitec
"TRUECOPY16S"	SANYO_CDRW161040	R-Quest
"CRD-BP5"	SANYO_CDRW241040	Sanyo
"CDBP-241040S"	SANYO_CDRW241040	Lacie
"TRUECOPY24S"	SANYO_CDRW241040	R-Quest
"CRD-BP6"	SANYO_CDRW321040	Sanyo
"CDBP-321040S"	SANYO_CDRW321040	Lacie
"CDW-900E"	SONY_CDW900E	Sony
"CD-R CDU920S"	SONY_CDU920S	Sony
"CDS615E"	SONY_CDU920S	Olympus
"CD-R1002"	SONY_CDU920S	Hightech
"CD-R 650"	SONY_CDU920S	Optima
"CD-R CDU924S"	SONY_CDU924S	Sony
"CD-R CDU940S"	SONY_CDU924S	Sony
"CDS620E"	SONY_CDU924S	Olympus
"CD-R2001"	SONY_CDU924S	Smart & Friendly
"CD-R2004"	SONY_CDU924S	Smart & Friendly
"CD-R CDU948S"	SONY_CDU948S	Sony
"CD-RW CRX140S"	SONY_CRX140	Sony
"CD-Writer+ 9200"	SONY_CRX140	Hewlett Packard
"CD-RW CRX145S"	SONY_CRX145	Sony
"CD-Writer+ 9400"	SONY_CRX145	Hewlett Packard
"CD-RW CRX160S"	SONY_CRX160	Sony
"CD-Writer+ 9600"	SONY_CRX160	Hewlett Packard
"CD-R50S"	TEAC_CDR50S	Teac
"CD-R50S-000"	TEAC_CDR50S	Teac
"RCD 4X4"	TEAC_CDR50S	Pinnacle
"CDVR4X4"	TEAC_CDR50S	Mitsubishi
"CD-R55S"	TEAC_CDR55S	Teac
"CD-R55S-000"	TEAC_CDR55S	Teac
"RCD 4X12"	TEAC_CDR50S	Pinnacle
"CD-R4012"	TEAC_CDR55S	Smart & Friendly
"CD-R4012SAF"	TEAC_CDR55S	Smart & Friendly
"CDR4120"	TEAC_CDR55S	Traxdata
"WT412"	TEAC_CDR55S	Waitec
"CD-R56S4"	TEAC_CDR56S4	Teac
"CD-R56S"	TEAC_CDR56S	Teac
"CDR6240"	TEAC_CDR56S	Traxdata
"CD-R6024"	TEAC_CDR56S	Smart & Friendly
"WT624"	TEAC_CDR56S	Waitec
"CD-R58S"	TEAC_CDR58S	Teac
"WT824"	TEAC_CDR58S	Waitec
"CD-W54S"	TEAC_CDW54	Teac
"CD-W512S"	TEAC_CDW512	Teac

"CD-W512SB"	TEAC_CDW512	Teac
"CD-W516S"	TEAC_CDW516	Teac
"CDR100"	YAMAHA_CDR100	Yamaha
"CDR102"	YAMAHA_CDR102	Yamaha
"CDR200"	YAMAHA_CDR200	Yamaha
"CDR200I"	YAMAHA_CDR200	Yamaha
"CDR4200"	YAMAHA_CDR200	Traxdata
"CDR400c"	YAMAHA_CDR400	Yamaha
"CDR400I"	YAMAHA_CDR400	Yamaha
"CD-R4006"	YAMAHA_CDR400	Smart & Friendly
"CDVR4X6"	YAMAHA_CDR400	Mitsubishi
"CDR4600"	YAMAHA_CDR400	Traxdata
"CRW2260"	YAMAHA_CRW2260	Yamaha
"CDRW2260 PRO"	YAMAHA_CRW2260	Traxdata
"CRW4260"	YAMAHA_CRW4260	Yamaha
"CDRW4260 PRO"	YAMAHA_CRW4260	Traxdata
"WT4046"	YAMAHA_CRW4260	Waitec
"CRW2216S"	YAMAHA_CRW2216	Yamaha
"CRW4416S"	YAMAHA_CRW4416	Yamaha
"CDRW-4416S"	YAMAHA_CRW4416	Memorex
"CRW6416S"	YAMAHA_CRW6416	Yamaha
"CRW8424S"	YAMAHA_CRW8424	Yamaha
"CRW8824S"	YAMAHA_CRW8424	Yamaha
"CRW2100S"	YAMAHA_CRW2100	Yamaha
"CRW2200S"	YAMAHA_CRW2200	Yamaha
"CRW3200S"	YAMAHA_CRW3200	Yamaha
"CRW-F1S"	YAMAHA_CRWF1	Yamaha